

**Yale**<sup>®</sup>  
**400 Series**

**CAUTION**  
An incorrectly installed or improperly adjusted door closer can cause property damage or personal injury. These instructions should be followed to avoid the possibility of misapplication or misadjustment.

**Non Hold Open Door Closers**  
**Models – 400**  
**TJS400**  
**TJ400**  
**TJL400**  
**PA400**


# Installation Instructions

80-9344-1101-010 (06-09)

- With or without suffix "DL" (Delayed Action) closing.
- With or without suffix "M" with metal Cover.

Note: For Special Applications a separate door and frame preparation template is packed with these instructions. Use this instruction sheet for installation sequence and closer adjustments only.

**Regular Arm Installation**  
Closer mounts on hinge (pull) side of door.  
See Page 3.  
Closer cover not shown




Left Hand Door - LH  
Right Hand Reverse - RHR

Right Hand Door - RH  
Left Hand Reverse - LHR

---

**Top Jamb Installation**  
Closer mounts on frame face on opposite to hinge (push) side of door.  
See Page 4.  
Closer cover not shown




Right Hand Door - RH  
Left Hand Reverse - LHR

Left Hand Door - LH  
Right Hand Reverse - RHR

Hinge Edge of Door

---

**Parallel Arm Installation**  
Closer mounts on opposite to hinge (push) side of door.  
See Page 5.  
Closer cover not shown




Right Hand Door - RH  
Left Hand Reverse - LHR

Left Hand Door - LH  
Right Hand Reverse - RHR

Hinge Edge of Door

# Components:



# Figure 1




- It is recommended that the door, on which the door closer will be installed, be hung on ball bearing hinges. Door must swing freely.
- A separate door stop, supplied by others, is recommended to prevent damage to the door closer, closer arm; or to the door, frame or adjacent walls.
- Door and Frame must be properly reinforced, or use of special fasteners employed, to prevent the mounting screws from pulling out.
- All dimensions are given in inches with corresponding metric dimensions (millimeters) in parentheses.

## Preparation for Fasteners

## Figure 2

Fasteners		Door or Frame	Drill-Sizes
Standard	#14 type "A" S.M. screw Arm: 1-1/4" (32 mm.) Closer: 2-3/4" (70 mm.)	Wood	7/32" (5.56 mm.)
	1/4" - 20 machine screw	Metal	drill: #7 (0.201" dia.) tap: 1/4" - 20
Optional	Sex nuts and bolts 	Hollow-Metal	9/32" (7.00 mm.) through; 3/8" (9.50 mm.) on door face opposite to closer
		Aluminum or Wood	3/8" (9.50 mm.) through
	Through-bolts and grommet-nuts 	All	9/32" (7.00 mm.) through; 3/8" (9.50 mm.) dia. x 3/8" (9.50 mm.) deep on door face opposite to closer

Template



Do Not Scale Drawing

Right Hand Door Shown


Dimensions are in inches (mm).

● 486 Backplate  
Mounting Hole Only

Opening	Dimension A	
	inches	mm
To 100°	7-5/8	194
101° to 120°	6-5/8	168
121° to 150°	4-5/8	117
151° to 180°	4-1/8	105

Installation Sequence


- Select angle of opening and use dimensions shown to locate 4 holes on door for closer body or backplate and 2 holes on frame face for arm shoe. For applications that are different from above, a separate template will be required.
- Prepare door and frame for fasteners. See "Preparation for Fasteners", Figure 2, Page 2.
- *Mount 486 Backplate ... only if required.*
- Install closer with power adjustment nut toward lock edge of door. **Valves UP for Right hand door – Valves DOWN for Left hand door.**
- Remove forearm screw from elbow joint and disassemble arm. See Figure 1. Fasten arm shoe (with rod and tube assembled) to frame face.
- Mount main arm onto closer pinion shaft, aligning arm mark "S" with pinion flat. Secure with main arm screw.
- **Reassemble arm.** Adjust forearm length so that it will be perpendicular (at a 90° angle) to the door face when connected to the main arm. Secure with forearm screw.
- Adjust closer (see Page 6) and install cover.



# Installation Instructions



## Top Jamb

### Template



### Installation Sequence



- Select angle of opening and use dimensions shown to locate 4 holes on frame face for closer body *or* backplate and 2 holes on door for arm shoe. For applications that are different from above, a separate template will be required.
- Prepare door and frame for fasteners. See "Preparation for Fasteners", Figure 2, Page 2.
- *Mount 486 Backplate ... only if required.*
- Install closer with power adjustment nut toward lock edge of door. **Valves UP for Left hand door – Valves DOWN for Right hand door.**
- Remove forearm screw from elbow joint and disassemble arm. See Figure 1. Fasten arm shoe (with rod and tube assembled) to door.
- Mount main arm onto closer pinion shaft, aligning arm mark "S" with pinion flat. Secure with main arm screw.
- **Reassemble arm.** Adjust forearm length so that it will be perpendicular (at a 90° angle) to the door face when connected to the main arm. Secure with forearm screw.
- Adjust closer (see Page 6) and install cover.



# Installation Instructions

# Parallel Arm

## Template



Do Not Scale Drawing

Left Hand Door Shown

Dimensions are in inches (mm).


Opening	Dimension A		Dimension B	
	inches	mm	inches	mm
To 100°	8-3/4	222	9-1/4	235
101° to 130°	7-1/4	184	7-3/4	197
131° to 150°	6-1/4	159	6-3/4	171
151° to 180°	5-1/4	133	5-3/4	146

● 488 Droplate Mounting Hole Only


## Installation Sequence

- Select angle of opening and use dimensions shown to locate 4 holes on door for closer body *or* droplate and 4 holes on underside of frame for soffit plate. For applications that are different from above, a separate template will be required.
- Prepare door and frame for fasteners. See "Preparation for Fasteners", Figure 2, Page 2.
- *Mount 488 Droplate ... only if required.*
- Install closer with power adjustment nut toward lock edge of door. **Valves DOWN for Left hand door – Valves UP for Right hand door.**
- Mount soffit plate to frame. Disassemble arm at forearm-screw (See Figure 1) and attach adjusting rod and connecting tube to soffit plate.
- Install main arm on pinion shaft ...See Main Arm Installation Instructions at right.
- **Reassemble arm.** Preload is accomplished by adjusting forearm length so that it will set arm elbow about 1-1/2" (38mm) from the door face when connected to the main arm. Secure with forearm screw.
- Connect to main arm. Secure with forearm screw.
- Adjust closer (see Page 6) and install cover.

## Main Arm Installation Instructions



\*Note: To mount main-arm close closer-valve "S" and turn pinion-shaft over 50° to overcome door interference.



To Install Main Arm:

- Close Valves S & L.
- Rotate Pinion Shaft in excess of 50°.
- Align Arm Mark with Pinion Flat, "Y"



**Right Hand Door, "Z" Left Hand Door.**

- Secure with main arm screw.

# Unit Adjustment


## Closing Speed Controls (Figure 1A or 1B and 2.)

- Valve "S" Controls Sweep Range.
- Valve "L" Controls Latch Range.
- Optional Valve "D" Controls Delay Range





## Closing Power Control (Figure 3)

- Adjust as required.



## Opening Door Control (Figure 4.)

- Backcheck ("B") valve controls the hydraulic resistance to door opening. NEVER close this valve completely – it is not to provide a positive stop.
- Backcheck position ("P") valve controls the door angle where backcheck cushioning starts. Valve normally closed.



**An ASSA ABLOY Group brand**  
 3000 Highway 74 East • Monroe, NC 28112  
 Tel: (800)-438-1951 • Fax: (800)-338-0965  
 www.yalecommercial.com