




Cheshire, CT 06410 203-699-3300 (Ph)
203-699-3365 (Cust. Serv. Fax)
203-699-3078 (Tech. Serv. Fax)

Installation and Operation of the Catalog Number 5541M-Y6 Millennium System Master



COPYRIGHT NOTICE

© 2003

IMPORTANT INFORMATION

Limitation of liability

This product has been designed to meet the requirements of Underwriters Laboratories, Inc., Standard 2017 and 864. Installation in accordance with this manual, applicable codes, and the instructions of the Authority Having Jurisdiction is mandatory. The manufacturer shall not under any circumstances be liable for any incidental or consequential damages arising from loss of property or other damages or losses owing to the failure of products beyond the cost of repair or replacement of any defective products. The manufacturer reserves the right to make product improvements and change product specifications at any time.

While every precaution has been taken during the preparation of this manual to ensure the accuracy of its contents, the manufacturer assumes no responsibility for errors or omissions.

FCC Warning

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Compliance Statement

Millennium System Master, when properly installed, operates with a Local Protected Premises Fire Alarm System in accordance with the following standard:

- Underwriters Laboratories Standard 864

Millennium System Master, when properly installed, can also be configured to operate as a self-monitored evacuation device, in accordance with the following standard:

- Underwriters Laboratories Standard 2017

Content

Chapter 1	System overview and operation	1
1.1	System overview	1
1.2	Operations Review	1
1.3	Controls and Indicators	1
1.4	Operating the Panel	5
Chapter 2	Installation	7
2.1	Installation checklist	7
2.2	Installing the cabinet	7
2.3	Installing Power	7
2.4	Wiring a Satellite Panel	10
2.5	Connecting Speaker/Amplifiers	11
2.6	Connecting External Initiating Inputs	11
2.7	Connecting to Output Relay	12
2.8	Connecting External Initiating Input to Fire Alarm Panel	12
2.9	Connecting to a UL Listed Telephone Access Module	13
2.10	Connecting to Remote Paging Units	14
2.11	Adjusting Audio Levels	15
Chapter 3	Programming	16
3.1	Overview	16
3.2	Local Alarm Input Assignment	16
3.3	Relay Output Assignment	16
3.4	Device Commission	16
3.5	Dynamic Zone Control™	17
3.6	Communications Setup	17
3.7	Panel Address Assignment	17
3.8	Panel Mode	17
3.9	Auto Learn Mode	17
3.10	Zone to Input Assignment	18
3.11	Voice Message Setup	18
3.12	Standby Power Mode	19
3.13	Remote Programming	
3.14	Text Output String	
3.15	Security	19
Chapter 4	Maintenance	20
4.1	Preventive Maintenance	20
4.2	Preventive Maintenance Schedule	20
Chapter 5	LCD Messages and Troubleshooting	21
5.1	Normal Mode	21
5.2	Troubleshooting and Trouble Messages	22
Appendix A	Calculations	26
	Battery calculation worksheet	26
	5532M Audio amplifier voltage drop calculation	27
	5532M Audio am. circuit max. wire length calculation	28
	Suggested RS-485 Network topology	28
Appendix B	Programming template	29
Appendix C	Panel specifications	30
Appendix D	Wiring	31

Chapter 1 - System Overview and Operation

1.1 - System overview

The Millennium System Master is a Four Zone Emergency Evacuation and Routine Signaling control panel that can be programmed to operate in two mode types: Master Mode or Satellite Mode. In either mode, the panel provides reliable emergency and non-emergency notification. In addition to signaling notification, the panel provides area and plant wide voice communications for emergency and non-emergency use. See Figure 1.

The following features are built in:

- 67 field selectable audible tones (See Table 1)
- Audio, voice & power supervision
- Microphone and input supervision
- Up to 4 five-second field recordable voice messages
- Hand-held microphone paging
- Standby power by using EBPS10 Booster Power Supply
- Up to 64 Satellite units addressable through RS485 network
- Output & Trouble Relays designed for fail-safe operation
- Multiple knockouts for easy cabinet entry
- LED Alarm & Status Indication
- 40 character LCD display for system status messages
- Program lockout key
- Adjustable output volume control
- Text output capable with Edwards message center signs

1.1.1 - Master Mode

In Master mode, the panel will be in standby normal operation waiting for either emergency or non-emergency keypad or external initiation. While there is no keypad or external initiation, the panel will perform continuous supervision on the following: RS-485 network via serial polling of configured devices, audio signal output wires, external input channels, remote power loss sense, microphone, audio amplifier and STDBY power input (when enabled). Any encountered troubles will be posted both visually, on the panel's LCD screen, and audibly from the panel's internal piezo buzzer.

During panel initiation of emergency and non-emergency activity, supervision (with the exception of RS-485 polling) will occur after 30 seconds of operation from the start of the initiation request. Polling will continue regardless of the panel's activity state.

1.1.2 - Satellite Mode

When in this mode, the panel will operate the same as in Master mode, except it will not supervise RS-485 network devices. It may, however, respond to serial commands from another panel configured as a master. All supervisory updates will occur once every 30 seconds.


1.2 - Operations overview

In the absence of any alarm, supervisory trouble, or non-emergency events, the control panel monitors the entire system for integrity.





When panel encounters either an emergency or non-emergency event, the panel conducts the following:

- Energizes appropriate output relays (K1-K4) associated with programmed input
- Activates programmed alarm tone/voice audio output
- Enables the appropriate alarm LED on the front panel
- Runs the appropriate programmed output response for the local or external input that signaled the event
- Communicates programmed Dynamic Zone Control event information to appropriate serial devices (Master Mode only)





1.3 - Controls and Indicators




(1) Function Buttons

Button	Description
	In Setup mode: changes currently selected program variable to next available program variable. From Master/Satellite mode: Initiates zone paging menu.
	From Master/Satellite mode: Selects panel setup mode.
	From Setup mode: Selects next program function. In Setup mode: Selects next available input or output to be programmed or assigned. From Master/Satellite: Allows viewing of current trouble condition(s).
	In Setup mode: changes currently selected program variable to previous selection. From Master/Satellite: Allows silencing of local trouble buzzer.

(2) Local Alarm Initiating Inputs

Button	Description
	From Master/Satellite mode: Initiates local alarm program 1 or selects Zone A for local paging. On steady until either CANCEL button is pressed or another local alarm is initiated.
	From Master/Satellite mode: Initiates local alarm program 2 or selects Zone B for local paging. On steady until either CANCEL button is pressed or another local alarm is initiated.
	From Master/Satellite mode: Initiates local alarm program 3 or selects Zone C for local paging. On steady until either CANCEL button is pressed or another local alarm is initiated.
	From Master/Satellite mode: Initiates local alarm program 4 or selects Zone D for local paging. On steady until either CANCEL button is pressed or another local alarm is initiated.

(2) Local Alarm Initiating Inputs

Button	Description
	From Master/Satellite mode: Cancels active local alarm program and transmits zone broadcast serial data to serial devices. From Setup mode: Terminates setup mode and returns panel to normal operation.

(3) Common System LEDs

LED	Description
Alarm	Flashing Green when there is an active alarm event occurring on local alarm program inputs. (buttons 1 - 4)
Trouble	Flashing Red when there is a fault with a monitored circuit or system component, when in Setup mode or when the panel is in STDBY power mode.
EXT Input	Flashing Green when there is one or more active external input(s) occurring on the external input channels or if the system audio channel is enabled coming from a Master panel.
BATTERY	Steady Green when the panel has sensed AC power loss and is on STDBY power





Figure 1. Millennium System Master

1.4 - Operating the Panel

1.4.1 - Resetting the panel

Pressing the  button places the panel in the alarm-reset state. The panel should not be reset until the appropriate authority has determined that the hazard is no longer present.

When you reset the panel:

- All local alarm program input LEDs will turn off.
- Active tone/voice audio output is disabled.
- All dynamic zones are disabled (Master panel only).
- All output relays are de-energized.
- Trouble LED will turn off temporarily until supervisory status update is restored. If the panel is configured as Master mode, supervisory status update will occur immediately; if the panel is configured as a Satellite mode, supervisory status will update within 30 seconds. The LED will remain off until it detects system trouble.
- When reset is complete, the local panel buzzer will turn off.

In this state:


- Alarm, trouble, and output relays are returned to the inactive state.
- STDBY POWER detection remains off until supervisory status update resumes.

If at the conclusion of the reset an active external input is detected, the panel will treat the event as a new event and activate the programmed responses.



To reset the panel:

1. Press the  button.

1.4.2 - Silencing the local panel Trouble buzzer

Pressing the  button silences the local buzzer on the panel. While in silence mode, the buzzer will sound once every 10 seconds for 0.5 seconds. This silence mode is restored to continuous mode only after a panel reset.

To silence the panel Trouble buzzer:

1. Press the  button on the panel.
2. Determine the cause of the trouble condition by pressing the  button.

1.4.3 - External Input Devices (EID)

External Input Devices (EID) connected to the panel's external input channels cannot be reset from the front panel. If an EID is active and the alarm condition must be cleared, the EID must then be manually reset at the point of origin.



WARNING

The EID should not be disabled until the cause of the alarm is determined and problem is resolved.


Resounding an alarm condition

Pressing the local alarm buttons (1-4) turns the audible devices back on if they were previously disabled or cancelled.

1.4.4 - Performing an Evacuation Drill or Walk Test

You can perform an EVAC drill or Walk Test by simply activating any one of the local alarm buttons. Tone/Voice, output relays and zones associated with the selected alarm button will be enabled. See the programming section for Local Input, Output Relays and Zone assignment. It is recommended that the user reserve a single local alarm button for EVAC drill, Walk Test or both. When programming the local alarm button, all zones and outputs relays should be assigned to this alarm button.

To perform an Evacuation Drill or Walk Test:

1. Press the user defined local alarm button.
2. To stop the EVAC drill or Walk Test, press the  button.

**THIS PAGE
INTENTIONALLY
LEFT BLANK**

Chapter 2 - Installation

2.1 - Installation checklist

- ☐ **Prepare the site.** Make sure the installation location is free from construction dust and debris and extreme temperature ranges and humidity.
- ☐ **Unpack the equipment.**
- ☐ **Install the cabinet.** See "Installing the Cabinet" for dimensions.
- ☐ **Plan wire routing.** See Appendix D or the panel label.



WARNING

Prior to making any electrical connections, ensure power is disconnected.

- ☐ **Connect the field wiring.** See Appendix D or the panel label. Meter for opens, grounds, and shorts before connecting.
- ☐ **Connect AC power and ground.** See Figure 4 and Appendix D or the panel label.
- ☐ **Connect Standby power.** See Figure 5 and Appendix D or the panel label. **NOTE:** When the System Master is used with a fire alarm panel, Standby Power **MUST** be installed and enabled.
- ☐ **Program the panel.** Refer to Chapter 3.
- ☐ **Verify operation.**
 1. Initiate contacts--listen for tones
 2. Push initiation buttons - listen for tones

3. Break audio & power leads to test supervision. Panel should go into trouble.
4. Adjust audio levels.
5. Check program switch is locked, deadfront is installed and door is locked.

2.2 - Installing the cabinet

Cabinets can be surface mounted or semi-flush mounted. See Figure 2 for framing and mounting dimensions.

2.2.1 - Surface Mounting

1. Position the cabinet on the finished wall surface.
2. Fasten the cabinet to the wall surface where indicated in Figure 2 using (4) 1/4" x 2" lag screws for wood, (4) 1/4" x 1" sheetmetal screws for steel, or (4) 1/4" x 2 1/4" wedge anchors for cement.


2.3 - Installing Power



DANGER

High voltage present when power applied. Prior to making any electrical connections, ensure power is disconnected.

1. Review specifications Appendix C for power requirements. Provide branch circuit wiring rated for panel requirements.
2. Connect green ground wire to terminal "G" on terminal block TB5 (Figures 3 and 4).
3. Connect incoming Neutral to terminal "N" on terminal block TB5. Connect incoming Hot to terminal "L" on terminal block TB5 (Figures 3 and 4).



NOTE: System Master Shown without Doors Installed

Figure 2. Panel Dimensions

4. When using an auxiliary power supply, connect Stdby Power (-) terminal (TB9) on the panel to the (-) connection on the auxiliary power supply. Connect Stdby Power (+) terminal (TB9) on the panel to the (+) connection on the auxiliary power supply. (See Figures 3 and 5.)

NOTE: For detailed wiring information, refer to the installation instructions supplied with the auxiliary power supply.




Figure 3. PC Board Locations




Figure 4. Installing AC Power




Figure 5. Connecting to an Auxiliary Booster Power Supply

2.4 - Wiring a Satellite Panel

The Millennium System Master is capable of driving up to 64 Satellite Panels. Connect the System Masters together as described here (See Figures 3 and 6).

1. Connect the RS485 wire from +TX/RX (TB8) on the Master Panel to terminal +TX/RX (TB8) on the Satellite Panel. Connect the RS485 wire from -TX/RX (TB8) on the Master Panel to -TX/RX (TB8) on the Satellite Panel.
2. Connect from MAIN OUT (+) (TB10) on the Master Panel to SYS_AUD (+) (TB13) on the Satellite Panel. Connect from MAIN OUT (-) (TB10) on the Master Panel to SYS_AUD (-) (TB13) on the Satellite Panel ending the loop with a 2.2K ohm end-of-line resistor (Part No. EOL-2.2).
3. Speaker/Amplifiers can be connected to the Satellite Panel as described in Section 2.5. NOTE: Speaker/Amplifiers connected to a Satellite Panel are NOT addressable and connections from +TX/RX and -TX/RX are unnecessary.




Figure 6. Connecting Satellite Panels to the Master Panel

2.5 - Connecting Speaker/Amplifiers

The Millennium System Master is capable of driving a total of 200 (64 of which can be addressable) 5532M Series speaker/amplifiers. Connect the console to the speaker/amplifiers as described below (See Figures 3 and 7).

1. Connect 10V RMS audio line (or 5V RMS for live voice evacuation) from "Main Out" (terminal block TB10) to the first 5532M speaker/amplifier. For connections to the 5532M speaker/amplifier, refer to the instructions supplied with the unit.

2. Continue to connect remaining 5532M series speaker/amplifiers as shown in Figure 7 ending the loop with a 2.2K end-of-line resistor (Part Number EOL-2.2).
3. For 5532M-485 Series speaker/amplifiers, connect the RS485 wire from +TX/RX (TB10) on the console board to terminal +TX/RX on the RS485 COMM board. Connect the RS485 wire from -TX/RX (TB10) on the console board to -TX/RX on the RS485 COMM board. For further installation details for 5532M-485 series, refer to installation instructions P/N 3100345.




Figure 7. Connecting 5532M Series Speaker/Amplifiers to Audio Main Out

2.6 - Connecting External Initiating Inputs

The initiating contacts operate on a pyramid-type priority system. Output from a contact closure on Input 1 overrides the output from a contact closure on Inputs 2, 3 and 4. The output from a contact closure on Input 2 overrides the output from a contact closure on Inputs 3 and 4. Likewise, the output from a contact closure on Input 3 overrides the output from a contact closure on Input 4. The output from a contact closure on Input 4 cannot override the output from any other external input.

1. Remove all test resistors from the input terminals. Install 4.7K ohm resistors, Cat. No. EOL-4.7, on terminals that will not have initiating contacts connected to them.
2. Connect normally-open initiating contact(s) to input terminals IN1, IN2, IN3, IN4 on External Input terminal block, TB14 (see Figures 3 and 8) as required. Install 4.7K ohm resistors, Cat. No. EOL 4-7, at the end of each circuit as shown in Figure 8.

NOTE: If connecting an external input to a Fire Alarm Panel, refer to Section 2.8.




Figure 8. Connecting Normally-Open Initiating Contacts

2.7 - Connecting to Output Relay

Up to four loads can be connected to the external output relays. Refer to Figures 3 and 9 for connections and to Appendix C, Panel

Specifications, for maximum contact ratings. Output relays are fail-safe; if the relay coil is faulty, power to the panel is lost or the relay driver fails, the relay, although de-energized, will activate and the load will be energized.




Figure 9. Connecting Output Relays (General Purpose)

2.8 - Connecting External Initiating Input to Fire Alarm Panel

NOTE: When the System Master is used with a fire alarm panel, Standby Power **MUST** be installed and enabled.

The System Millennium Control Master can be connected to a fire alarm panel for use in evacuation of the building. Connect the fire alarm panel through a Cat. No. 6254B-003 relay to the console as shown in Figure 10.




Figure 10. Connecting External Initiating Input to Fire Alarm Panel

2.9 - Connecting to a UL Listed Telephone Access Module

Connect the System Millennium Master to a Telephone Access Module (TAM) as shown in Figure 11. Use only a UL Listed telephone access module with a dry contact initiation and 600 ohm balanced or unbalanced output




Figure 11. Connecting to Telephone Access Module (TAM)

2.10 - Connecting to Remote Paging Units

Up to twenty-five 5542RPUs can be connected to the panel. The first paging unit connected has the highest priority on the system followed by decreasing priorities for the remainder of the 5542RPU paging units connected in series. (Refer to Figures 3 and 12.)

All connections referred to below are made from terminals on terminal block TB13 on the System Master to terminal block TB1 on the 5542RPU.

1. Connect from +VS on the System Master to +VS on the 5542RPU.
2. Connect from -VS on the System Master to GND on the 5542RPU.
3. Connect from RPU/AUD + on the System Master to A+ on the 5542RPU.
4. Connect from RPU/AUD - on the System Master to A- on the 5542RPU.
5. Connect from P_OUT on the System Master to Pin on the **FIRST** 5542RPU in the series.
6. Connect from PQ+ on the System Master to PQ on the 5542RPU.
7. Connect from Pout on the first 5542RPU in the series to Pin on the next 5542RPU in the series. Repeat for each 5542RPU in the series.
8. For ancillary use only--NOT supervised.




Figure 12. Connecting to a Cat. No. 5542RPU Remote Paging Unit

2.11 - Adjusting Audio Levels

Volume levels can be adjusted for main output, paging, playback, local monitor speaker, and for telephone access module (TAM) audio. Refer to Figure 13 to see locations for potentiometers.

NOTE: Volume increases by turning the potentiometer clockwise. ↻


Page Adjust - Adjusts local microphone level

Playback Adjust - Adjusts voice message level

Local Adjust - Adjusts level of local monitor speaker

TAM Level Adjust - Adjusts level of external telephone audio coming from telephone access module

Main Adjust - Adjusts main system audio out. Needs to be at minimum of 2.5V RMS. Adjusting the main system audio to less than 2.5V RMS will result in a trouble indication.



Chapter 3 - Programming

3.1 - Overview

Program options and settings

The features and functions of the Millennium System Master are programmable. To customize the panel, program it as described in this chapter.

Programming Notes

To enable programming, you must insert the key (supplied with the console) into the lock on the inside door (below the LCD panel) and turn it clockwise 90°.

NOTE: The key cannot be removed when programming is enabled.


Pressing **FUNC** at any time during a setup will advance to the next available setup screen.

Pressing **CANCEL** (cancel button) at any time during setup mode will exit the setup mode. *Pressing cancel will not cancel changes you have made to the panel programming.*

The panel will automatically exit setup mode if no buttons are pressed for 60 seconds.

3.2 - Local Alarm Input Assignment

Allows any of the selected tone or voice messages to be programmed to local alarm inputs 1 through 4 located on the front panel.



Using the LCD screen and the tone chart in Table 1 or located on the inside front cover of the panel, press the **FUNC** button to enter the "Setup mode." The LCD displays "Tone Label" with Input 1 and its tone assignment as shown here.

1. Change the tone assignment on Input 1 by pressing the **ZONE** button (change button) until the desired tone is reached.


NOTE: Pressing the **TRBL** button (back button) at any time will change the tone selection to the previously selected tone.

2. To change the tone assignment on Local Input 2 press the **TRBL** button (next button) and repeat step 1.
3. To change the tone assignment on Local Inputs 3 and 4 repeat steps 1 and 2.
4. After changing the tone assignment on Local Input 4, press **TRBL** to advance to Relay Setup Mode. Relay Assignment is discussed in Section 3.3.

3.3 - Relay Output Assignment

Relay output assignment allows local alarm inputs, once activated, to latch and control up to four relay outputs simultaneously. Relays will deactivate once the user cancels the alarm input. Trouble relay latches when supervisory or communication troubles are encountered.

From the LCD screen, press **FUNC** button until LCD displays:



In this program mode, both Local and External Inputs are assigned to a combination of output relays K1-K4. When a Local or External Input Alarm is selected, the configured relays will stay energized as long as the alarm input is active. This is useful for driving other industrial or control signals during tone and voice activation from the panel.

1. In the "Relays: R1 R2 R3 R4" program mode, press the **ZONE** button to deactivate the current relay R1 selection for Input 1.

NOTE: "N" - the relay WILL NOT activate upon alarm or trouble conditions on the displayed input

"Y" - the relay WILL activate upon alarm or trouble conditions on the displayed input

2. Press **TRBL** to advance to the next available relay. Repeat step 1.

NOTE: Press **TRBL** to return to the previously programmed relay.

3. Repeat steps 1 and 2 to finish relay output assignment on Relays R3 and R4 on Input 1.
4. Press **TRBL** to advance to the next alarm input, Input 2.
5. Repeat steps 1 - 4 for each of the 4 local inputs as required.
6. Pressing **TRBL** after activation/deactivation of Relay 4 on Local Input 4 will advance to "Device Commission" setup. See Section 3.4.

3.4 - Device Commission

Device Commission allows for manual entry of serial devices located on the RS-485 data network. Once the device map is configured, devices will be continuously polled for their activity status. Devices not responding to a POLL command from the Master Panel, or devices reporting supervisory trouble can be viewed from the Trouble View on the front panel.

When the panel is in Master mode, the setup screen allows manual assignment and entry of serial devices into the device map and is used for future polling and zoning of devices on the RS-485 communications network.

IMPORTANT: This should only be done when devices are being commissioned for the very first time or devices are removed or added to the network. When a serial device is commissioned on the RS-485 network, it is assigned a unique physical address ranging from 00-3F Hex (64 decimal addresses). **No two devices should be assigned the same address.**

1. From the Master LCD screen, press **FUNC** until LCD displays:



NOTE: Device commission is only for use on the Master panel. If Satellite panels are connected to the Master panel, all devices on the satellite panel are non-addressable.

1. For each serial device on the network, press **TRBL** to display the device address. Once that device is displayed, press **ZONE** to store the device (or if the device has been removed from the network, press **ZONE** to change it to "Erased.")

NOTE: Pressing the **TRBL** button at any time will jump back to the previous serial device address.

NOTE: A device that is "Stored" will be polled by the Millennium System Master. A device that has been "Erased" is NO

longer active in the device map and will not be addressed during supervisory polling from the panel.

NOTE: "Stored" devices can also support zoning functions during panel output activity.

3.5 - Dynamic Zone Control™

When the panel is in Master mode, the Dynamic Zone Control (DZC™) program setup provides zone assigned for each of the serial devices "Stored" in the device map (See Section 3.4). The panel supports up to four zones but only one zone can be assigned to each serial device.

The zone assignment assigns a zone to each serial device. If the zone is not set, it will automatically default to Zone A.

NOTE: Non-serial devices connected to the Millennium System Master will be activated with any zone activation.

1. From the Master LCD screen, press **FUNC** until LCD displays:

Device Zone Assign
Device: 00 Zone: A

2. Press **ZONE PAGE CHG** to change the displayed device to the desired zone (A - D).
3. Press **TRAIL VIEW NEXT** to advance to the next available serial device configured in the device map.
4. Repeat steps 2 and 3 until all serial devices have been assigned a zone.

NOTE: Serial devices not manually assigned zones will default to Zone A.

NOTE: In order for a device to receive a new Dynamic Zone Control assignment, the panel must complete one successful poll to the unit. Please allow approximately 1 minute for poll completion prior to testing and verification of zones.

3.6 - Communications Setup

Communications Setup allows for setup of the baud rate. Supported baud rates are: 1200, 2400, 9600, 19200. Default is 9600 BPS. Parity, data and stop bits are not programmable and are restricted to No Parity, 8 data bits and 1 stop bit.

NOTE: Before setting the panel baud rate, be sure to properly configure remote devices to the same baud rate as the panel baud rate. This will avoid a trouble alarm associated with communication failures on remote serial devices. Refer to instructions supplied with remote devices for settings.

1. From the LCD screen, press **FUNC** until LCD displays:

Communications Setup
BAUD: 9600,N,8,1

2. Press **ZONE PAGE CHG** to advance to the desired baud rate.

3.7 - Panel Address Assignment

The panel address assignment is used only when the panel is in Satellite mode. Each satellite panel must be assigned a unique station address. **The valid address range is 00-3F.**

CAUTION

To avoid a communication failure, do not assign an address that has been assigned to another serial device on the network. See Section 3.4.

1. From either the LCD screen, press **FUNC** until LCD displays:

Set Panel Address
Address: 00

2. Press the **ZONE PAGE CHG** button to advance to the next available address. **The valid address range is 00-3F.**
3. Press the **TRAIL VIEW BACK** button to return to the previous address selection.

3.8 - Panel Mode

The panel must be configured as either a Master or Satellite panel. Panels configured as Master will initiate poll requests, assign dynamic zones and communicate to serial devices. Panels configured as Satellite will only reply to poll/status requests and accept dynamic zone commands from the Master Panel.

1. From the LCD screen, press the **FUNC** button until LCD displays:

Panel Mode
Mode: MASTER

2. Press the **ZONE PAGE CHG** button to select the desired mode of operation.

NOTE: When changing from "Satellite" to "Master" mode, be sure that previously "Stored" devices in the device map have been configured properly for baud rate (Section 3.6) and device commission selection (Section 3.4). This will eliminate any possible communication trouble conditions encountered once the panel resumes the polling sequence.

3.9 - Auto Learn Mode


The Auto Learn Mode allows for automatic entry and storage of serial devices into the device map. During this program setup, the panel will detect active devices on its RS-485 network and build a device map based on the active devices found. The device map is then stored in the panel's non-volatile memory indefinitely. As new serial devices are added or removed from the network, this utility should be run for updating the device map.

1. From the LCD screen, press the **FUNC** button until LCD displays:


AUTO LEARN MODE
<chg> - Yes, <func> - No

2. Press the **ZONE PAGE CHG** button to begin auto learn mode detection.

NOTE: If you do not want to use the auto learn mode, pressing **FUNC** will advance to the next setup screen.

When the  button is pressed, the panel will begin to poll all unit addresses beginning at address 00 and ending at address 3F. As devices are found, they are stored in the panel's device map. The program setup will run two times for redundancy and reliability. Once complete, the LCD screen will display:

AUTO LEARN COMPLETE
 <func> - continued

Press  button to advance to the next setup screen.

After running the Auto Learn mode, devices detected and stored in the device map should be verified by the user in the Device Commission program setup (See Section 3.4). Each configured device can be viewed.

When devices are first stored in the device map, they are assigned Dynamic Zone A. Dynamic zones for the individual devices can be changed in the Device Zone Assignment Program Setup (See Section 3.5).


NOTE: *In order for a device to receive a new Dynamic Zone assignment, the panel must complete one successful poll to the serial unit. Please allow approximately 1 minute for poll completion prior to testing and verification of zones.*

Only Master panels support Dynamic Zones.


3.10 - Zone to Input Assignment

Each serial device on the panel's RS-485 network can be assigned a specific dynamic zone from A through D. Dynamic zone assigned for each device configured in the device map is stored in non-volatile memory. Each time a serial device is polled, its stored Dynamic Zone assignment command is sent out. When system audio is initiated from the Master panel, those devices with matching Dynamic Zones will broadcast the Master panel's system audio; all other serial devices will be prohibited from the current audio broadcast.


NOTE: *Non-serial devices connected to the Master panel will broadcast system audio for any and all zones.*

1. From the LCD screen, press the  button until LCD displays "Zones: A B C D" as shown below. From this mode, both local and external alarm inputs can be assigned to a combination of zones (up to 4 zones maximum for each alarm input)


ZONES: A B C D
 Input 01 Y Y Y Y

2. To activate or deactivate the current Zone for Alarm Input 1, press the  button. More than one zone can be active for each input.

NOTE: *"N" - the zone WILL NOT broadcast when the input is active*
"Y" - the zone WILL broadcast when the input is active

3. Press  to advance to the next zone. Repeat step 2.

NOTE: Press  to return to the previously programmed relay.

4. Repeat steps 2 and 3 to finish zone to input assignment on Input 1.
5. Press  to advance to the next alarm input, Input 2.
6. Repeat steps 2 - 5 for each of the 4 local inputs as required.

7. Pressing  after activation/deactivation of Zone D on Input 4 will advance to "Voice Message Setup" menu. See Section 3.11.

3.11 - Voice Message Setup

The panel features voice messaging capability. This program setup allows the user to easily record and store voice messages in four separate message locations. Voice messages can then be selected and assigned to Local Alarm Inputs in the "Local Inputs" Assignment program setup screen.

CAUTION

The panel supervision must detect recorded audio in each location or the panel will receive a trouble indication.


From the LCD screen, press the  button until LCD displays:

Voice Message Setup
 Location: 01 REC-OFF

This mode allows recording and storage of voice messages for later playback. The panel supports up to four five-second voice messages. Message lengths greater than five seconds are possible by extending the recording length.

Note: *Voice messages that become longer than five seconds will physically require two or more message locations. For example, a 20-second message would occupy all four message locations limiting the user to only ONE message. If a 20-second message is desired, record only in the first message location (tone 17) and assign this location to any four of the Local Alarm Inputs for playback. If other locations are assigned for playback, the message may be partial or incomplete. For a 15-second message, record in the second message location (tone 18); for a 10-second message, record in the third message location (tone 19). Any of these messages can be assigned to any of the Local Alarm Inputs.*

To record a message:

1. Press the microphone's press-to-talk (PTT) button and speak clearly into the microphone. When finished recording, release the PTT button.
2. To advance to the next voice message location, press the  button.
3. Repeat steps 1 and 2 until all desired messages have been recorded.


NOTE: *To play back the message(s) that you have recorded, cancel out of programming mode (by pressing) and activate the local input with the voice message programmed on it. If the voice message does not play, ensure that the input is programmed to play the recorded message. See Section 3.2 and Table 1.*

3.12 - Standby Power Mode

The panel can be programmed to accept standby power from an Edwards EBPS10 auxiliary power supply or other UL regulated standby power source listed for fire. When this feature is enabled, the standby power input is continuously monitored for integrity. When disabled, the standby power input is only monitored when the panel has detected the loss of AC main power.

NOTE: When the System Master is used with a fire alarm panel, Standby Power **MUST** be installed and enabled.



1. From the LCD screen, press the **FUNC** button until LCD displays:



2. Press the **ZONE** button to enable/disable the standby power mode.

3.13 - Remote Programming

Millennium System Master panels can be programmed remotely using Edwards System Master programmer P/N XXXXXX. Enabling program mode to 'ready' begins to upload and download the sequence to the programmer. Once programming is complete, mode will change back to disabled.




The panel will be inoperative until the program sequence is completed and the panel has timed out of setup mode.


3.14 - Text Output String

Millennium System Master Panel is capable of interfacing to Edwards Message Center signs. Key inputs 1-4 can be programmed to recall message sign file labels A-Z. Up to two file labels can be assigned to each of the four key inputs. Each input can also address individual signs between addresses 00 and FF.

Text Output String Format is as follows:



Example: Text Output String



NOTES: Sign address 00 transmits to all signs on the network.
Any unused file labels should be programmed with a zero "0" in the file label location as shown in the example above.

3.15 - Security

The panel programming can be secured after programming is complete. Using the keys supplied with the console, turn the lock on the inside door (below the LCD panel) until it stops. In this position, all alarm and paging inputs can be activated but the function key is disabled.

Table 1. Tone Programming

Tone	Description	HEX
Ding-Dong	Percussive pairs of 700 and 570 Hz tones, each damped to zero	01
Warble	575 and 770 Hz alternately, 87 ms each	02
Siren	600-1250 Hz up and down sweep in 8 seconds and repeat	03
Stutter	Percussive 470 Hz, 83 ms on, 109 ms off	04
Slow Whoop	600-1250 Hz upward sweep in 4 seconds and repeat	05
Beep	470 Hz, 0.55 seconds on, 0.55 seconds off	06
Chime 1	700 Hz percussive repeat at 1 Hz	07
Fast Whoop	600-1250 Hz upward sweep in 1 second and repeat	08
Hi/Lo	780 to 600 Hz alternately, 0.52 seconds each	09
Rapid Siren	600-1250 Hz up and down sweep in 0.25 seconds and repeat	0A
Yeow	1250-600 Hz downward sweep in 1.6 seconds and repeat	0B
Horn	470 Hz continuous	0C
Air Horn	370 Hz continuous	0D
Dual Tone	450-500 Hz, 0.4 to 0.5 second cycle	0E
Chime 2	575 Hz percussive repeat at 1 Hz	0F
Westminster	Two measures, 411 Hz, 520 Hz, 407 Hz, 312 Hz	10
Three Blind Mice	Four measures, 787 Hz, 714 Hz, 625 Hz, 952 Hz, 333 Hz	11
Phasor	416-625 Hz up and down sweep in 13 ms and repeat	12
Telephone	570 and 770 Hz alternately, 50 ms each for 1.2s, 1.5s delay and repeat	13
Staircase	440-2000 Hz up and down steps, 750 ms delay and repeat	14
3 Tone Alert	463, 641 and 896 Hz, 200 ms each, 1 second delay and repeat	15
Presignal Chime	470 Hz percussive repeat at 1.5 Hz, followed by Message 1	16
Message 1	Field recorded voice message	17
Message 2	Field recorded voice message	18
Message 3	Field recorded voice message	19
Message 4	Field recorded voice message	1A
NEPA Whoop	Three 422-775 Hz upward sweeps, 850 ms each, 1s delay and repeat	1B
3 Pulse Horn	470 Hz, 3 0.5 second pulses separated by 0.5 seconds followed by a 1.5 second delay and repeat-- <i>For Evacuation Use Only</i>	1C
3 Pulse Air Horn	370 Hz, 3 0.5 second pulses separated by 0.5 seconds followed by a 1.5 second delay and repeat-- <i>For Evacuation Use Only</i>	1D
3 Pulse Dual Tone	450-500 Hz, 0.4 to 0.5 second cycle, 3 0.5 second pulses separated by 0.5 seconds followed by a 1.5 second delay and repeat-- <i>For Evacuation Use Only</i>	1E
3 Pulse Chime 2	575 Hz, 3 0.5 second pulses separated by 0.5 seconds followed by a 1.5 second delay and repeat-- <i>For Evacuation Use Only</i>	1F
European Police	969 Hz and 800 Hz alternately 0.250 seconds each	20
European Fire	982 Hz and 864 Hz downward sweep in 0.134 seconds	21
European Slow Whoop	658 Hz to 1312 Hz upward sweep in 3 seconds followed by 0.5 second delay and repeat	22
European General	1087 Hz for 0.5 seconds followed by 0.5 second delay and repeat	23
European Toxic	982 Hz continuous	24
European Police 2	554 Hz and 440 Hz alternately 0.800 seconds each	25
European Stutter	3876 Hz for 0.146 seconds followed by 0.102 seconds delay and repeat	26
European Sweep	1315 Hz to 413 Hz downward sweep in 1.17 seconds and repeat	27
Telephone 2	Alternate tones at 567 Hz and 326 Hz, for 0.052 seconds each	28
Buzzer 1	1315 Hz and 746 Hz alternating for 0.003 seconds each	29
Genesis Horn Cont.	Continuous Genesis horn	2A
Genesis Horn Temp.	Temporal Genesis horn	2B
Warning 1	1207 Hz and 493 Hz, alternately 0.002 seconds each	2C
Warning 2	2336 Hz and 493 Hz, alternately 0.005 seconds each	2D
Warning 2 Beep	0.500 second of 2336 Hz and 493 Hz, each alternating for 0.005 seconds, followed by 1 second delay	2E
Caution	453 Hz for 0.040s, 235 Hz for 0.020s, 235 Hz for 0.160s, 260 Hz for 0.050s, 260 Hz for 0.1009s, 235 Hz for 0.050s	2F
Multi-Tone	376, 357, 352, 382, 355, 375, 384, 375 and 364 Hz alternately on for 0.050 seconds	30
Attention	2232, 4545, 3704, 2777, 4347, 3704, 2500 Hz alternately on for 0.003 seconds	31
High Freq. StdyAlert	2500 Hz continuous	32
High Freq. Fast Siren	2500 to 3048 Hz up and down sweep in 0.130 seconds	33
High Freq. Slow Siren	2500 to 3048 Hz up and down sweep in 0.500 seconds	34
DIN PFEER	Ramp downward from 1336 Hz to 522 Hz in 1.2 seconds and repeat	35
NFS 32 001	584 Hz for 0.100 seconds and 461 Hz for 0.400 seconds	36
Ode to Joy	6.45 seconds of melody followed by 1 second delay and repeat	37
Twinkle Little Star	13.2 seconds of melody followed by 1 second delay and repeat	38
Dueling Banjos	10.84 seconds of melody followed by 1 second delay and repeat	39
La Cucaracha	7.10 seconds of melody followed by 1 second delay and repeat	3A
Yellow Rose of Texas	19.34 seconds of melody followed by 1 second delay and repeat	3B
Presignal Message 2	470 Hz percussive repeat at 1.5 Hz, followed by Message 2	3C
Presignal Message 3	470 Hz percussive repeat at 1.5 Hz, followed by Message 3	3D
Presignal Message 4	470 Hz percussive repeat at 1.5 Hz, followed by Message 4	3E
Non Repeating Voice Msg 1	Non Repeating Field Recorded Voice Message	3F
Non Repeating Voice Msg 2	Non Repeating Field Recorded Voice Message	40
Non Repeating Voice Msg 3	Non Repeating Field Recorded Voice Message	41
Non Repeating Voice Msg 4	Non Repeating Field Recorded Voice Message	42

Chapter 4 - Maintenance

4.1 - Preventive Maintenance

Before commencing testing, notify all areas where the alarm sounds and off-premises locations that receive alarm and trouble transmissions that testing is in progress.

- Records of all testing and maintenance shall be kept as required by the authority having jurisdiction.
- Required tools:
 - Slotted or Phillip style #2 screwdriver, insulated
 - Alligator style jumper clips (12 inch lead length)
 - Digital multi-meter
 - Front panel door key
 - Program mode security key
 - Sound level meter

- A complete check of installed field wiring and devices should be made at regular intervals in accordance with NFPA 72 requirements. This includes testing all alarm and supervisory initiating devices and circuits and any off-premises connections.
- Panel operation should be verified in the alarm, supervisory and trouble modes.
- To ensure that the panel can be powered when primary power is lost, standby power to the panel should be periodically inspected, tested, and replaced (at a minimum) every four years.

4.2 - Preventive Maintenance Schedule


Refer to NFPA 72, Chapter 7, Inspection, Testing and Maintenance for more information on required inspection and testing methods and frequency of fire alarm systems and devices. For detector sensitivity and functionality testing, refer to the detector manufacturer's installation instructions.

Chapter 5 - LCD Messages and Troubleshooting

5.1 - Normal Mode

When in normal mode, the following messages will be displayed on the LCD screen of the Millennium System Master. It should be noted that the zones shown below will not appear if the panel is in satellite mode.

Display




Illuminated LED's

None


Description

Displayed when the panel is in Standby mode. If panel is set for Master, bottom line will be as shown. If panel is set as Satellite, bottom line on LCD display will read "SATELLITE MODE." Panel is performing supervision while this message is being displayed.




None

Displayed when the panel microphone push to talk (PTT) button is depressed. Message will return to normal upon release.



Input LED (1, 2, 3, or 4) based on input key selected


When alarm is activated using local inputs 1, 2, 3 or 4 on the keypad, the display will show "TONE OR VOICE LABEL." Message will return to standby message when cancel/alarm silence key is pressed.



External Input

Displayed when the telephone access input is activated via contact closure from the UL Listed telephone access module interface. Message will return to standby message upon contact release.

Display




Illuminated LED's

External Input

Description

Displayed while a message is being sent via a 5542RPU microphone. Message will return to standby message once the RPU request line is inActive.




External Input on Satellite panel


Displayed with the panel is in Satellite Mode and a serial system audio command is received, along with the zone qualifier, the panel will switch on and pass sytem audio through to its conventional system amplifiers. Message will return to standby message when either a serial system audio disable command is received or if the user presses the cancel/alarm silence key.

5.2 - Troubleshooting and Trouble Messages

When in trouble mode, the following messages will be displayed on the LCD screen of the Millennium System Master. When a trouble indication is received, the trouble LED will illuminate and the display will read as shown below. The number after "TROUBLE STATUS" indicates the number of troubles the panel has received. To view the trouble, press the **TRBL VIEW NEXT** button. If more than one trouble status exists, you can press the **TRBL VIEW NEXT** button again to see each of the remaining indications. The following information will describe the trouble indications, what they mean and possible solutions to the problem.



Display




Illuminated LED's

Trouble

Description

Wiring is faulty on MAIN OUT terminals. The panel is not able to detect the end-of-line resistor on the line. Ensure that end-of-line resistor is properly connected and wiring loop is not broken or shorted.

Display




Illuminated LED's

Trouble


Description

The panel has detected a missing end-of-line resistor, trouble with wiring (break in wiring or fault wiring), or a speaker/ amplifier has lost power.




Trouble


The panel has detected bad wiring or a faulty or missing end-of-line resistor on one of the external input contacts.



Trouble

The amplifier or associated circuitry is faulty, MAIN OUT volume adjustment is set below 2.5V RMS.

To increase MAIN OUT volume, turn the potentiometer located on the main PC board clockwise. Press the  button to silence the trouble see if the trouble has been cleared.




Trouble

(1) or more message locations are empty or the associated circuitry is faulty.

Message locations can be checked by pressing the input button that the message location is associated with. If the message location is not being used, it can be temporarily assigned to an input contact. See Chapter 3 - Programming.


NOTE: In the case of voice message failure, the System Master will automatically generate a 3 Pulse evacuation tone within 30 seconds of an evacuation alarm activation. All four LEDs associated with the input keys will be illuminated during this activation.



Trouble

Indication caused by a decrease of the battery backup voltage to less than 19V. Check to see that the battery backup is connected properly and that the batteries are properly charged.

Display




Illuminated LED's

Trouble


Description

Indication occurs when the microphone is missing or wiring is faulty.




Trouble

When Standby Power Mode is enabled and AC power is lost, this indicates that the panel is running on battery backup



Trouble

Panel has lost communication with serial device indicated.



Trouble

Satellite panel assigned to this device address is reporting a trouble condition on one or more functions. To see the trouble indications, you must use the TRBL VIEW on the satellite panel.

Appendix A - Calculations

Battery calculation worksheet

Use this worksheet to determine the minimum amperage capacity required for the panel's standby power source. You can obtain operating current requirements for amplifier units from their respective installation sheets. For 5532M series amplifiers, the audio signal draw for each audio amplifier is approximately 2 mA at 470 Hz.

NOTE: Base panel includes the main controller board with no system audio output loading and only EOL resistors.

Standby current: Master and Satellite - 230 mA

Alarm current: Master and Satellite - 215 mA

NOTE: Alarm current with no amplifier loading is less because EOL resistor path is opened during alarm condition and closed during supervision.

	Standby Current (mA)	Alarm Current (mA)
Base Millennium System Master Panel [1]	<input type="text"/>	<input type="text"/>
RPU Current draw (See Form A)	<input type="text"/>	<input type="text"/>
Audio Amplifier Loading (See Form B)	<input type="text" value="0"/>	<input type="text" value="0"/>
Total Current	<input type="text"/>	<input type="text"/>
Required standby and alarm time	x <input type="text"/>	x <input type="text"/>
	Standby time 24 or 60 hour	Alarm time
		5 min = 0.083 10 min = 0.167 15 min = 0.250 30 min = 0.500
	<input type="text"/> mAh	+ <input type="text"/> mAh
		= <input type="text"/> mAh
		/1000
		Battery amp hour total = <input type="text"/> Ah
		x 1.2
		<input type="text"/>
		+ 0.25
		Minimum battery size [2] = <input type="text"/> Ah

Form A

Product	Quantity	Standby current (mA)	Qty x Standby current (mA)	Paging current	Qty x Paging current (mA)
5542RPU	<input type="text"/>	5	<input type="text"/>	22	<input type="text"/>
	<input type="text"/>		<input type="text"/>		<input type="text"/>
	<input type="text"/>		<input type="text"/>		<input type="text"/>
	<input type="text"/>		<input type="text"/>		<input type="text"/>
	<input type="text"/>		<input type="text"/>		<input type="text"/>
	<input type="text"/>		<input type="text"/>		<input type="text"/>
	<input type="text"/>		<input type="text"/>		<input type="text"/>
Total RPU Current [2]	<input type="text"/>		<input type="text"/>		<input type="text"/>

[1] See Appendix C for the maximum number of amplifiers supported by the panel.

[2] RPU power supplied by panel cannot exceed 0.55A (paging current). If more than 0.55A is required, you must reduce number of RPU devices supplied by the panel.

Form B

Audio Amplifier	Quantity of Audio Amplifiers [1]	Individual Amplifier Current Draw (mA)	Total Current Draw (quantity x Amplifier current in mA)
5532M			
Total current draw for all amplifiers =			


[1] See Appendix C for the maximum number of amplifiers supported by the panel.

5532M Audio Amplifier Voltage Drop Calculation

Circuit length (single conductor)		Total Circuit current to unit		Wire resistance per 1000 ft [1]		Voltage drop
feet	x 2 x	Amps	X	ohms	/1000 =	

Audio output from panel or previous unit's End of line circuit		Voltage drop		End of line voltage [3]
	-		=	

Voltage drop		Audio output from panel or previous unit's end of line circuit [2]		Voltage drop %
	/		=	



Example -- Determine voltage drop from Panel to Unit 2

Steps

1. Obtain single conductor wire length from Panel to Unit 2.
2. Obtain total circuit current from Panel's audio output
3. Using wire type from below and table from above, calculate voltage drop to Unit 2.
4. Unit 2 End of Line Voltage = Panel Audio Output **or** Previous Unit's End of Line Voltage - Unit 2 Voltage Drop

Notes

- [1] Use 1.6 for 12 AWG and 2.5 sq mm wire, 2.6 for 14 AWG and 1.5 sq mm wire, 4.2 for 16 AWG and 1.0 sq mm wire and 6.6 for 18 AWG and 0.75 sq mm wire
- [2] Panel audio output voltage is 10.6V_{rms}
- [3] In order to produce a minimum 75 dBA output, voltage should not be less than 9V_{rms}

5532M Amplifier Circuit Maximum Wire Length Calculation

Use this worksheet to determine the maximum wire length of an Audio Amplifier appliance circuit. Fill in one worksheet for each Audio Amplifier appliance circuit connected to the panel.

Wire length matrix

Wire lengths in the following table are based on a voltage drop of 1.6 volts or 15% of the Panel's audio output End of line appliance.

Current required (A)	Maximum wire length (ft)			
	18 AWG	16 AWG	14 AWG	12 AWG
0.25	584	950	1460	2170
0.50	292	474	730	1084
0.75	194	316	486	722
1.00	146	236	364	542
1.25	116	190	292	434
1.50	92	158	242	362

Maximum signal loss allowed [1]

$$\frac{\boxed{} \text{ V}}{1000}$$

Wire resistance per 1000 ft/pair x 2 [2]
(2x the number in note 2)

$$\frac{\boxed{}}{\boxed{}} \text{ ohms}$$

$$\boxed{} \text{ ohms}$$

Total operating current required

$$\frac{\boxed{}}{\boxed{}} \text{ A}$$

Maximum wire length





$$\boxed{} \text{ ft}$$

Notes

[1] 1.6V_{rms} loss in order to produce 75 dBA minimum.

[2] Use 1.6 for 12 AWG and 2.5 sq mm wire, 2.6 for 14 AWG and 1.5 sq mm wire, 4.2 for 16 AWG and 1.0 sq mm wire and 6.6 for 18 AWG and 0.75 sq mm wire

Suggested Network Topology Node Schemes



Appendix B - Programming Template

(1) Project Name _____ Project Address _____
 Programmed by _____ Date _____ Tested by _____ Date _____

(2) Local Input Assignment

Input 1 - Tone # _____
 Input 2 - Tone # _____
 Input 3 - Tone # _____
 Input 4 - Tone # _____

(3) Output Relay Assignment

Relays	R1		R2		R3		R4	
	Y	N	Y	N	Y	N	Y	N
Input 1	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Input 2	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Input 3	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Input 4	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

(4) Alarm Input to Zone Assignment

Zones	ZA		ZB		ZC		ZD	
	Y	N	Y	N	Y	N	Y	N
Input 1	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Input 2	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Input 3	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Input 4	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

(5) Communications Setup

Baud Rate ☐ 1200 ☐ 2400 ☐ 9600 ☐ 19200

(6) Satellite Panel Address

Satellite Unit Name _____ Address _____

(7) Panel Mode

Mode ☐ Master ☐ Satellite

(8) Standby Power Mode

Mode ☐ Enabled ☐ Disabled

(9) Device Map and Dynamic Zone Assignment

Device Address	Description	Zone	Erased	Stored
(Circle one only)				
00		A B C D	<input type="radio"/>	<input type="radio"/>
01		A B C D	<input type="radio"/>	<input type="radio"/>
02		A B C D	<input type="radio"/>	<input type="radio"/>
03		A B C D	<input type="radio"/>	<input type="radio"/>
04		A B C D	<input type="radio"/>	<input type="radio"/>
05		A B C D	<input type="radio"/>	<input type="radio"/>
06		A B C D	<input type="radio"/>	<input type="radio"/>
07		A B C D	<input type="radio"/>	<input type="radio"/>
08		A B C D	<input type="radio"/>	<input type="radio"/>
09		A B C D	<input type="radio"/>	<input type="radio"/>
0A		A B C D	<input type="radio"/>	<input type="radio"/>
0B		A B C D	<input type="radio"/>	<input type="radio"/>
0C		A B C D	<input type="radio"/>	<input type="radio"/>
0D		A B C D	<input type="radio"/>	<input type="radio"/>
0E		A B C D	<input type="radio"/>	<input type="radio"/>
0F		A B C D	<input type="radio"/>	<input type="radio"/>
10		A B C D	<input type="radio"/>	<input type="radio"/>
11		A B C D	<input type="radio"/>	<input type="radio"/>
12		A B C D	<input type="radio"/>	<input type="radio"/>
13		A B C D	<input type="radio"/>	<input type="radio"/>
14		A B C D	<input type="radio"/>	<input type="radio"/>
15		A B C D	<input type="radio"/>	<input type="radio"/>
16		A B C D	<input type="radio"/>	<input type="radio"/>
17		A B C D	<input type="radio"/>	<input type="radio"/>
18		A B C D	<input type="radio"/>	<input type="radio"/>
19		A B C D	<input type="radio"/>	<input type="radio"/>
1A		A B C D	<input type="radio"/>	<input type="radio"/>
1B		A B C D	<input type="radio"/>	<input type="radio"/>
1C		A B C D	<input type="radio"/>	<input type="radio"/>
1D		A B C D	<input type="radio"/>	<input type="radio"/>
1E		A B C D	<input type="radio"/>	<input type="radio"/>
1F		A B C D	<input type="radio"/>	<input type="radio"/>

Appendix B - Programming Template (Cont'd)

(1) Project Name _____ Project Address _____
 Programmed by _____ Date _____ Tested by _____ Date _____

(9) Device Map and Dynamic Zone Assignment (Cont'd)				
Device Address	Description	Zone	Erased	Stored
(Circle one only)				
20		A B C D	<input type="radio"/>	<input type="radio"/>
21		A B C D	<input type="radio"/>	<input type="radio"/>
22		A B C D	<input type="radio"/>	<input type="radio"/>
23		A B C D	<input type="radio"/>	<input type="radio"/>
24		A B C D	<input type="radio"/>	<input type="radio"/>
25		A B C D	<input type="radio"/>	<input type="radio"/>
26		A B C D	<input type="radio"/>	<input type="radio"/>
27		A B C D	<input type="radio"/>	<input type="radio"/>
28		A B C D	<input type="radio"/>	<input type="radio"/>
29		A B C D	<input type="radio"/>	<input type="radio"/>
2A		A B C D	<input type="radio"/>	<input type="radio"/>
2B		A B C D	<input type="radio"/>	<input type="radio"/>
2C		A B C D	<input type="radio"/>	<input type="radio"/>
2D		A B C D	<input type="radio"/>	<input type="radio"/>
2E		A B C D	<input type="radio"/>	<input type="radio"/>
2F		A B C D	<input type="radio"/>	<input type="radio"/>
30		A B C D	<input type="radio"/>	<input type="radio"/>
31		A B C D	<input type="radio"/>	<input type="radio"/>
32		A B C D	<input type="radio"/>	<input type="radio"/>
33		A B C D	<input type="radio"/>	<input type="radio"/>
34		A B C D	<input type="radio"/>	<input type="radio"/>
35		A B C D	<input type="radio"/>	<input type="radio"/>
36		A B C D	<input type="radio"/>	<input type="radio"/>
37		A B C D	<input type="radio"/>	<input type="radio"/>
38		A B C D	<input type="radio"/>	<input type="radio"/>
39		A B C D	<input type="radio"/>	<input type="radio"/>
3A		A B C D	<input type="radio"/>	<input type="radio"/>
3B		A B C D	<input type="radio"/>	<input type="radio"/>
3C		A B C D	<input type="radio"/>	<input type="radio"/>
3D		A B C D	<input type="radio"/>	<input type="radio"/>
3E		A B C D	<input type="radio"/>	<input type="radio"/>
3F		A B C D	<input type="radio"/>	<input type="radio"/>

Appendix C - Panel Specifications

External Initiating Device Circuits (EID)	Contact Closure Initiating Circuit	4 total	
5532M Series Audio Amplifier Circuits	Class B, Style Y	200 maximum	
Maximum System Audio Output to 5532M Amplifier units		1.0 amp @ 10V RMS at ambient 25C	
AC input*	120V AC 50/60 Hz	Standby Current 0.14A	Alarm Current 0.37A
	240V AC 50/60 Hz	0.10A	0.22A
Base panel DC current draw**		230 mA	215 mA
Battery standby voltage		19 - 25.7V DC	
+VS RPU supply current (max.)		0.55A (used for Remote Paging Units)	
+VS RPU output voltage		+24V DC + 10% (main AC power present), 19 - 25.7V DC (battery standby)	
System Audio Output Circuit		Maximum loop resistance: 26 ohms Maximum loop capacitance: 440 µF	
External Initiating Device Circuit		Maximum loop resistance: 13 ohms Maximum loop capacitance: 15 µF	
Alarm and Trouble Output Contact		Form C: 4A @ 30V DC (resistive load) Form C: 5A @ 240V AC (general use)	
Environmental		Temperature: 0 - 49C (32 - 120F) Humidity: 5 - 93% relative humidity, non-condensing	
Terminal rating		All terminals rated for 12 to 18 AWG (0.75 to 2.5 sq mm)	
Serial communications	Style 4 Communication Circuit	Asynchronous communications Maximum resistance: 13 ohms Maximum capacitance: 0.03 µF	

*Full system load (except max. RPU loading)

**No load except EOL resistors on System Audio Out and External Initiating Input contacts

PAGE 33

