


INSTALLATION INSTRUCTIONS 🖤 PTS

The PD25-M-SVR (PD26 Mechanical) is our architectural grade 1 exit device. Electrified it comes equipped

with motorized latch retraction utilizing our PTS "Push to Set" technology.



PD25 Includes

- A. 6' 2-Pin Power Lead (not included with PD26
- B. Top & Bottom Latch
- C. PD25-M Device w/ MM module
- D. Rod Guides
- E. Strike
- F. SVR Rods
- G. End Cap
- H. 4 Screw Pack

Tools Required

Cordless Drill

U.S. Customer Support 1-888-622-2377 Visit our website for more details www.CommandAccess.com

Canada Customer Support 1-855-823-3002



TECHNICAL INFORMATION

- Input Voltage: 24VDC +/- 10%
- Wire gauge: Minimum 18 gauge
- Direct wire run no relays or access control units in-between power supply & module

Low Torque Mode

- Average Latch Retraction Current: 600 mA
- Average Holding Current: 150 mA
- Standard Torque Mode- Ships Standard
- Average Latch Retraction Current: 900 mA
- Average Holding Current: 215 mA


High Torque Mode

- Average Latch Retraction Current: 2 Amp
- Average Holding Current: 250 mA

SETTING PTS

MM4S Switches Switch 1 2 IN OFF Low Torque

SPECIFICATIONS



OPTIONAL

REX Switcн Rating: .5A @24VAC

Configuration: Green - Common (C)

BLUE - NORMALLY OPEN (NO)

GRAY - NORMALLY CLOSED (NC)

Important Info Make sure to set PTS before finishing installation!

Step 1- Select your preferred torque mode (ships in standard torque) Press the device push pad to the desired setting. (Recommend to fully depress and release 5%, giving the device a little room for changing door conditions.)

- Step 2- While depressing the push pad, apply power. (i.e. presenting the credential to the reader).
- **Step 3** Continue to keep pad depressed, the device will beep 6 times. After the beeps have stopped,

release the pad and now the adjustment is complete. If not to your liking repeat the three steps.

That's all there is to it.


Step 4- Once you found the right location, switch the dip switches to off to lock in programming.

BEEPS	Explanation	
2 Beeps	Over Voltage	> 30V unit will shut down. Check voltage & adjust to 24 V.
3 Beeps	Under Voltage	< 20V unit will shut down. Check voltage & adjust to 24 V.
4 Beeps	Failed Sensor	Verify all 3 sensor wires are installed correctly. Replace sensor if problem persists by contacting office.
5 Beeps	Retraction or Dogging failure	 Device physically binding during retraction or pulled from the dogged position. After 1st fail: 5 beeps then immediately attempts to retract again. After 2nd fail: 5 beeps with pause in-between for 30 seconds then device attempts to retract again. After 3rd fail: 5 beeps every 7 minutes, device will not attempt to retract. To Reset: Depress bar for 5 seconds at any time.
6 Beeps	Push to Set	Device is recording it's new position and power mode after the 6th beep.


TROUBLESHOOTING & DIAGNOSTICS


Visit our website for more details www.CommandAccess.com

2













TEMPLATE FOR SVR EXIT DEVICE



TEMPLATE FOR RIM EXIT DEVICES




TEMPLATE FOR SVR LATCHES



ver. 1.0 rev. 03/16 VERSION inches UNIT PAGE 1 OF 1 SCALE 1:1 IF PRINTED TO SIZE ANSI I TEMPLATE FOR NON-FIRE RATED TOP AND BOTTOM CHASSIS ASSEMBLY APPLICABLE FOR 2200, 7700 & 9800 SERIES DESCRIPTION 22901 La Palma Ave. Yorba Linda CA 22837 USA FR: (889) 622-2377 FAX: (888) 622-2302 Website: ccommandaccess.com imail:orders@c





- SURFACE OF DOOR WHERE EXIT DEVICE IS TO BE APPLIED MUST BE FLUSH SEE MASTER SHEET FOR AREAS REQUIRING REINFORCEMENTS
 - - SEE STRIKE TEMPLATE FOR TOP AND BOTTOM STRIKES.
- We recommend that all tapped holes be drilled & tapped in field tolerance on all dimensions $\pm 1/64"$ 1, 2, 0, 4, Ci