

INSTRUCTIONS FOR MOUNTING BOTTOM CASE KIT NO. 576

FOR INSTALLATION ASSISTANCE CALL SARGENT
AT 1-800-727-5477 • www.sargentlock.com

SARGENT

ASSA ABLOY

- STEP 1** Remove cover from bottom case on the door by removing 4 cover mounting screws. Slide cover up on the rod and remove 3 - bottom case mounting screws. Leave cover on the rod.
- STEP 2** Remove bottom strike and remount the 624 strike in place.
- STEP 3** Insert the bottom rod through the spring in retractor on 9700 bottom case.
- STEP 4** Mounting location of bottom case may vary depending on strike being used. See illustration below. If remounting is required, drill and tap for (3) #10-24 mach. screws.
- STEP 5** Mount bottom case to the door with 3 - #10-24 mach. screws or #10 WD screws.
- STEP 6** Adjust bottom rod to clear the strike when rail depressed and insert adjusting pin in bottom rod as shown in illustration. Place bottom cover on chassis and attach with (4) #8 screws provided.

