



ELECTRIC EXIT DEVICE KIT INSTALLATION INSTRUCTIONS AUTHORIZED EGRESS

K-131 FALCON 1690 AND 1790 SERIES FIRST CHOICE 3600 AND 3700 SERIES

MONITORS THE USE OF THE TOUCHBAR

Electrical Specifications:

SPDT Monitor Switch
Contacts Rated: 3A @ 125VAC
2A @ 30VDC

Wire Color Codes:

YELLOW - Common
RED - Normally Open
GRAY - Normally Closed

Installation:

1. Separate the touchbar from the exit device.
2. Drill a 3/8" diameter hole through the channel end cap and device channel for wire access from the access control system to the exit device.
3. Locate the K-131 Kit on the rear touchbar anchor assembly using the pin and flanges of the rear touchbar anchor assembly for positioning. Verify the switch arm is pre-actuated by the actuating pin of the rear touchbar anchor assembly.
4. Bend the tabs of the switch bracket to secure the switch bracket to the rear touchbar anchor assembly.
5. Route the lead wires along the outside edge of the device channel.
6. Secure the lead wires to the inside of the device channel using the supplied ty-wrap mount and ty-wrap.
7. Attach the touchbar to the exit device.

