



- NOTES:**
1. Do not scale drawing.
 2. Dimensions are in inches (mm).
 3. LHR door shown. Preparation is typical for both door hands.
 4. Minimum door stile width: 4-1/2 (114).
 5. Prepare mounting holes when installing the device.
 6. Unreinforced frames require blind rivet nuts (by others) to mount the strike.
 7. This hole MUST be field located using physical part as template, after installation is complete and device is fully operational.
 8. For recommended door reinforcements see template 7400-0000. Unreinforced doors require SNB option to mount the device components.
 9. Bottom bolt should retract to 1/8 (3.2) above floor strike. Floor coverings in the door path must be laid accordingly.
 10. Provide door stiffeners, as needed to prevent door collapse due to installation with power tools, or door use, or abuse.
 11. Device mount to hinge stile (not shown) requires hole location and preparation during device installation.
 12. For outside trim preparation and device mounting holes see appropriate trim template.

RESPONSIBILITY
 DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

1520 and 1520F Concealed Vertical Rod Exit Devices x Active Trim
 Application for Metal Door and Frame With 1/2" Threshold and 794 Optional Floor Strike
 Contact us for support at 1-855-557-5078.

ASSA ABLOY

SUPERSEDES	8/99	DO NOT SCALE DRAWING
TEMPLATE NUMBER	7415-0026	DATE 12-23