



NOTES:

1. Do not scale drawing.
2. Dimensions are in inches (mm).
3. LHR active pair shown. Preparation is typical for both hands.
4. Minimum door stile width 4-1/2 (114).
5. Prepare mounting holes when installing the device.
6. Lock support by door manufacturer.
7. For recommended door reinforcements see template 7400-0000. Unreinforced doors require SNB option to mount the device components.
8. Holes for optional SNB: 9/32 (7.00) dia. inside door face; 3/8 (9.50) dia. outside door face
9. Device mount to hinge stile (not shown) requires hole location and preparation during device installation.
10. For outside trim preparation see appropriate trim template.
11. Unless otherwise specified, door preparation and dimensional tolerances must conform to ANSI A115.1 (lock) and A115.14 (strike).
12. Dimensions given about a centerline are symmetrical.
13. Latchbolt centerline is 23/32 (18.2) below & Auxbolt centerline is 3/16 (4.8) above the centerline of lockfront.
14. Strike clearance required 7/8 (22.2) deep on inside and 1/8 (3.2) deep on outside face.

RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

1530 and 1530F Mortise Exit Devices with Optional 718 Open Back Strike
 Application to Pair of Metal Doors without Mullion
 Contact us for support at 1-855-557-5078.

ASSA ABLOY

SUPERSEDES	8/99	DO NOT SCALE DRAWING	
TEMPLATE NUMBER	7415-0032	DATE	12-23