



Notes:

1. Do not scale drawing.
2. Dimensions are in inches (mm).
3. Minimum Stile Width: 2 (51).
4. Maximum door Width: 42 (1067)
5. Prepare mounting holes when installing the hardware.
6. For recommended door reinforcements see template 7400-0000. Unreinforced doors require SNB option to mount the hardware
7. Holes for optional SNB: 9/32 (7.00) Dia. Inside door face; 3/8 (9.50) Dia. Outside door face.
8. Provide door stiffeners as needed to prevent door collapse due to installation with power tools, door use, or abuse.

RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

**620DB & 720DB Dummy Push Bar
Application for Metal Door**

Contact us for support at 1-855-577-5078.

ASSA ABLOY

SUPERSEDES	DO NOT SCALE DRAWING	
TEMPLATE NUMBER	7470-0720	DATE 01-24