



NOTES:

1. Do not scale drawing.
2. Dimensions are in inches (mm).
3. Minimum Stile Width: 2 (51).
4. Maximum door Width: 42 (1067)
5. Prepare mounting holes when installing the hardware.
6. Provide adequate door support to maintain door integrity after bar installation with power tools, door use, or abuse.
7. Wood screws (by others) permitted for solid core wood doors if pilot holes are used for installation and door label allows its use.

RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

620DB & 720DB Dummy Push Bar
Application for Wood or Composite Door

Contact us for support at 1-855-557-5078.

ASSA ABLOY

SUPERSEDES	05/15	DO NOT SCALE DRAWING
TEMPLATE NUMBER	7470-1720	DATE 03/24