

## RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

## 6100F & 7100F Rim Fire Exit Devices with 757F Strike

Application for Fire Labeled Metal Door and Frame or Mullion

Contact us for support at 1-855-557-5078.

## **ASSA ABLOY**

SUPERSEDES 05/15 DO NOT SCALE DRAWING

076.

7470-0002

1 01-24