

- 4. This preparation is an addition to preparation shown on device template.
- 5. See device template to locate centerline of device template.
- Shields for wiring access recommended for insulated and composite
- 7. Locate and prepare wiring access holes when installing device.

RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION

Experience a safer

7100 and 7200 Series Electric Exit Devices with Suffixes "D", "G", "-P", "-B", "-O", "-S", "-Safe", and '-Secure"

Preparation of Wiring Access for Metal or Wood Door and Frames (Not for Fire Labeled Devices) 1-855-557-5078 Ext. 2

www.accentra-assaablov.com

Copyright ©2024, ASSA ABLOY ACCENTRA™ Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of and more open world ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.



SUPERSEDES 7477-0001 02/24

Hinge Edge Detail

DO NOT SCALE DRAWING

TEMPLATE NUMBER 7477-0001

04/24