



RESPONSIBILITY
 DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

7110, 7115, 7110F
Surface Vertical Rod Exit Devices
 Standard Application for Metal Door and Frame

Contact us for support at 1-855-577-5078.

ASSA ABLOY

SUPSEDES	DO NOT SCALE DRAWING	
TEMPLATE NUMBER	7470-0010	DATE 01-24

Experience a safer and more open world