



**RESPONSIBILITY**  
 DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

**7220M, 7225M & 7220MF**  
**Concealed Vertical Rod Exit Devices**  
**for Narrow Escutcheon Trim**  
 Application for Metal Door and Frame  
 With 790 Floor Strike  
**Contact us for support at 1-855-577-5078.**

**ASSA ABLOY**

|                 |                      |            |
|-----------------|----------------------|------------|
| SUPERSEDES      | DO NOT SCALE DRAWING |            |
| TEMPLATE NUMBER | 7473-0020            | DATE 01-24 |