



NOTES:

1. Do not scale drawing. Dimensions shown in inches(mm).
2. LHR door shown. Preparation is typical for both door hands.
3. Prepare mounting holes when installing the hardware.
4. Holes for optional SNB: 3/8(9.50) Dia. Thru Transom.
5. Unless transom provides solid engagement for not less than (3) full screw threads, the SNB option is required.
6. Provide stiffeners, as required to prevent transom collapse due to installation with power tools, door use, or abuse.

<p>RESPONSIBILITY DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.</p>	<p>797 Auxiliary Bracket for Surface Vertical Rod Exit Devices Application to Flush Transom</p> <p>Contact us for support at 1-855-557-5078.</p>	<p style="text-align: center;">ASSA ABLOY</p> <table border="1" style="width: 100%;"> <tr> <td>SUPERSEDES</td> <td>8/99</td> <td colspan="2">DO NOT SCALE DRAWING</td> </tr> <tr> <td>TEMPLATE NUMBER</td> <td>7400-0797</td> <td>DATE</td> <td>12-23</td> </tr> </table>	SUPERSEDES	8/99	DO NOT SCALE DRAWING		TEMPLATE NUMBER	7400-0797	DATE	12-23
SUPERSEDES	8/99	DO NOT SCALE DRAWING								
TEMPLATE NUMBER	7400-0797	DATE	12-23							

Experience a safer and more open world