



Left Hand Shown

Notes:

- Do not scale drawing.
- Left hand door shown. Same dimensions apply for right hand door, measured from centerline of hinge or pivot.
- Template information based upon use of 4-1/2" hinges or 3/4" offset pivots.
- Dimensions are shown in inches and millimeters (mm).
- Hollow metal doors require channel or box-type reinforcement when thru-bolt mount is specified.
- Sex-nuts are required for wood or plastic faced fire-door installations.
- Minimum thickness recommended for reinforcements in hollow metal doors and frames is .1046 (2.66) unless noted otherwise.
- Maximum door opening is 110°.

Preparation for Fasteners			
	Fasteners	Door or Frame	Drill-Sizes
Standard	1/4" - 20 machine screw Sleeve nuts and bolts	Metal	Drill: #7 (0.201" dia.) Tap: 1/4" - 20
		Hollow Metal	9/32" (7 mm) through; 3/8" (9.5 mm) door face opposite to closer
		Aluminum or Wood	3/8" (9.5 mm) through
Optional	Through-bolts and grommet-nuts	All	9/32" (7 mm); 3/8" (9.5 mm) dia. x 3/8" (9.5 mm) deep on door opposite to closer

**Yale Series P400PTO Support Unit
With or Without 488 Drop Plate**

Combination Door Closer-Holder with Single Point Hold Open Stop (Push) Side of Door Installation

1-800-438-1951



www.yalecommercial.com

TEMPLATE NUMBER

7348-1802

DATE

02-09