

8800 Series Mortise Locks

Wood and H.M. Door Preparation

**Thru Bolted Escutcheon Plate Trim** 

ASSA ABLOY

SHEETS

1of 2

08/23

DO NOT SCALE DRAWING

DATE

11-23

SUPERSEDES

TEMPLATE NUMBER 7086-1201

DOOR AND FRAME MANUFACTURERS ARE **RESPONSIBLE FOR PROVIDING ADEQUATE** CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERTY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE. MATERIAL, OR METHOD OF CONSTRUCTION.

Experience a safer and more open world

Copyright © 2006, 2023, ASSA ABLOY Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

| Lock Function  | HOLES I    | HOLES IN DOOR |  |  |
|--|------------|---------------|--|--|
| 8800   | Outside    | Inside        |  |  |
| 8801, 8870DT, 8871DT<br>8872DT, 8880, 8881,8884<br>8885, 836A & B, 838A & B                                    | A, G       | A, G          |  |  |
| 8802, 8862, 8865   | A, C, G    | A, C, G       |  |  |
| 8805, 8807, 8808, 8824<br>8831, 8890, 8891   | A, B, G    | A, G          |  |  |
| 8808-2, 8811-2, 8812-2<br>8817-2, 8818-2, 8830-2<br>8860-2, 8894-2, 8895-2<br>8896-2, 8897-2, 8898-2<br>8899-2 | A, B, G    | A, B, G       |  |  |
| 8820, 8827, 8864   | A, B, C, G | A, C, G       |  |  |
| 8809, 8822, 8832, 8840<br>8847, 8860, 8861, 8867<br>8896, 8897, 8898, 8899                                     | A, B, G    | A, C, G       |  |  |
| 8833   | B, G       | A, G          |  |  |
| 8833, 8814-2   | B,G        | B,G           |  |  |
| 8834, 8834-2   | B,G        | A, B,G        |  |  |
| 8813ST, 8815   | B, G       | C, G          |  |  |
| 8823, 8829   | A, B, G    | G             |  |  |
| 8813ST-2   | B,G        | B, C, G       |  |  |
| 8814   | B, G       | G             |  |  |
| 8828   | G          | A, G          |  |  |
| 8835   | G          | A, C, G       |  |  |

RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

Experience a safer and more open world

8800 Series Mortise Locks Wood and H.M. Door Preparation Thru Bolted Escutcheon Plate Trim



| UPERSEDES          | 08/23  | DO NOT SCALE DRAWING |      |       |
|--------------------|--------|----------------------|------|-------|
| EMPLATE NUMBER 708 | 6-1201 | SHEETS 2 of 2        | DATE | 11-23 |

Copyright © 2006, 2023, ASSA ABLOY Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.