

P8700 | P8800 STRIKE TEMPLATE

APPLY TEMPLATE TO FRAME AT LATCH END

3"

For aluminum frames use
edges of template to
mark 3" blade stop cut

Align edge of
template with
door face

BAR HEIGHT

CENTERLINE

 Adams
Rite

ASSA ABLOY

adamsrite.com
80-0180-177_4

Drill two (2) $\frac{5}{32}$ " pilot holes for
self-tapping screws (If using rivnuts
drill two (2) $\frac{1}{4}$ " pilot holes)

1"

