



## **MODELS 735x28 & 735x312 DOUBLE DOOR STRIKE INSTALLATION INSTRUCTIONS**

1. Place the L-shaped Angle Bracket centered approximately 38" above the floor, flush with the edge of the inactive door. Using the bracket as a template, mark and drill four 1/8" diameter holes.
2. Fold the supplied template along the dotted line. Attach it to the Angle Bracket with two screws in the area marked for Keeper position.
3. Mount the Angle Bracket with template attached onto the inactive door. Tape the template to the inside face of the active door and mark and drill four 5/32" holes for the Lock Mounting Plate.
4. Mount the lock. Install the Keeper Assembly onto the bracket using two tamper-proof screws and nuts (supplied). Screws should be snug but not tight.
5. Follow steps 8 through 10 of the installation instructions for Models 715 and 265 to complete the installation.