

FOLD HERE AND ALIGN TEMPLATE ON HIGH EDGE OF DOOR BEVEL.

FOLD HERE AND ALIGN TEMPLATE ON HIGH EDGE OF DOOR BEVEL.

Test Fit Secondary Housing and Secondary Mounting Plate:

Prior to drilling the two lower 3/32" diameter holes, install the secondary mounting plate and test fit the secondary housing. Ensure the housing fits correctly over the mounting plate (the housing must be flush against the door and the top two housing trim screw holes must mate to their corresponding mounting plate trim holes). Adjust mounting plate as necessary.

METAL DOORS ONLY:
1/8" MIN. DEPTH HOLE
BOTH SIDES OF DOOR

NOTE: DO NOT DRILL THESE 3/32" HOLES UNTIL SECONDARY SIDE HOUSING IS TEST FITTED

IMPORTANT

WHEN PRINTING OR PHOTOCOPYING A TEMPLATE, ALWAYS SELECT PRINTING OPTIONS TO ENSURE THAT COPIES ARE PRODUCED WITHOUT SIZE ADJUSTMENTS. VERIFY THE DIMENSIONS OF THIS BOX ARE 2.000 X 2.000 INCHES ± 0.010.

**PDL6300
DL6300**
Double-Sided Locks



ALARM LOCK

345 Bayview Avenue, Amityville, New York 11701
For Sales and Repairs 1-800-ALA-LOCK
For Technical Service 1-800-645-9440
or visit us at <http://tech.napcosecurity.com/>

(Note: Technical Service is for security professionals only)
Publicly traded on NASDAQ Symbol: NSSC

© ALARM LOCK 2018

ENSURE THIS BOX IS 1 INCH X 1 INCH

(DOOR THICKNESS)

(DOOR THICKNESS)

