



Notes:

1. This template is an addition to the device template. Locate centerlines using horizontal and vertical references on device template.
2. Do not scale drawing.
3. Dimensions are in inches (mm).
4. LHR door shown. Preparation is typical for both door hands.
5. For door reinforcement see template T30800.
6. Prepare mounting holes when installing trim.
7. G810, G850, G855, and G859 trim require 3-1/2 (89) or wider door stiles.
8. Provide internal door support adequate to prevent door deformation from bolting trim to the device.

810, 850, 855, & 859 Series Narrow Escutcheon Trim
For ED4200(M), ED4400(M), or ED4800(M) Series
Rim and Vertical Rod Exit Devices
Metal Door Preparation

**Corbin
Russwin**

ASSA ABLOY

www.corbinrusswin.com

| | | |
|-----------------|-----------------|----------------------|
| SUPERSEDES | T30813-2 | DO NOT SCALE DRAWING |
| TEMPLATE NUMBER | T30813-3 | DATE 03-12 |