



**Notes:**

1. This template is an addition to the device template. Locate centerlines using horizontal and vertical references on device template.
2. Do not scale drawing.
3. Dimensions are in inches (mm).
4. LHR door shown. Preparation is typical for both door hands.
5. Provide adequate structural support to maintain door integrity during operation.
6. Prepare mounting holes when installing trim.
7. G810, G850, G855, and G859 trim require 3-1/2 (89) or wider door stiles.

**810, 850, 855 & 859 Series Narrow Escutcheon Trim**  
 With ED4200(M), ED4400(M), or ED4800(M) Series  
 Rim and Vertical Rod Exit Devices <sup>②</sup>  
**Wood or Composite Door Preparation**

**Corbin  
 Russwin**

**ASSA ABLOY**

www.corbinrusswin.com

SUPERSEDES T30848-1 DO NOT SCALE DRAWING

TEMPLATE NUMBER **T30848-2** DATE **02-09**