

All Functions And Trims Supersedes T30686 Dr. **Except Dummy Trim** Date 6-04

App.

T30686-1

Template Number

shown. All architectural builders hardware must

be installed on properly reinforced doors and frames, regardless of the type, material, or

method of construction.