



**Notes:**

1. Do not scale drawing. Dimensions are in inches (mm).
2. Position reinforcements according to hand of door. LHR door shown.
3. Refer to specific device and trim templates for additional reinforcements, cutouts and mounting hole requirements.
4. Provide 4-1/2" (114.3) wide or full stile width reinforcements.
5. Outside door face, bridge or channel reinforcement, required when outside trim is used.
6. Reinforcements should be adequate for machine screw holes (minimum engagement of 3 full threads). Maximum thickness 5/32 (4) for door skin and reinforcement.
7. Shields recommended for mortise lock installations.

Issue No. \_\_\_\_\_ Date \_\_\_\_\_

Customer's Name \_\_\_\_\_ Job Name \_\_\_\_\_

Customer's Order No. \_\_\_\_\_

Device	Template No.	Strike	Template No.	Trim	Template No.	Misc.	Template No.

**ED2000, ED4000, & ED5000 Series  
Master Reinforcement Template For  
Exit Devices and Trim**



SUPERSEDES T30800-1 | DO NOT SCALE DRAWING  
TEMPLATE NUMBER **T30800-2** | DATE **10-22**

www.corbinrusswin.com