

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALL ATION OF HARDWARE SHOWN ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

ED2200A and ED5200A Series Rim Fire Exit Devices with 650F30 Strike

Application for Fire Labeled Metal Door and Frame or Mullion



ASSA ABLOY

www.corbinrusswin.com

SUPERSEDES T30802-2 DO NOT SCALE DRAWING Г30802-