

proper installation of hardware shown.
All architectural builders hardware must
be installed on properly reinforced doors
and frames, regardless of the type,
material, or method of construction.

PULL AND CYLINDER EXIT TRIM

www.corbinrusswin.com
DO NOT SCALE DRAWING

SUPERSEDES T30477 PR. BTH

04/02/93 TEMPLATE T 3 0 4 7 7 -