

NOTE2

- 1. For 707A and 708A (KM) Mullion Frame Preparation Template, refer to T30882.
- 2. For other device and strike mounting specifications, refer to appropriate single door application template.
- *3. **Caution:** When glass bead shims are used to raise device off surface of door, refer to glass bead shim template T30494 for proper strike mounting dimensions.
- 4. For preparation of trim, refer to separate template.
- 5. Dimensions given in inches and (mm).

ED8200A Series
Rim Fire Exit Devices
Application to Metal, Wood or Composite Doors
With 707A and 708A (KM) Mullion



TEMPLATE NUMBER T30941-1 DO NOT SCALE DRAWING