

RESPONSIBILITY

Door and Frame Manufacturers are responsible for providing adequate construction or reinforcements for proper installation of hardware shown.
All architectural builders hardware must be installed on properly reinforced doors and frames, regardless of the type, material, or nethod of construction

K057

RIM CYLINDER EXIT TRIM

(EXCEPT NARROW STILE EXIT DEVICE)



www.corbinrusswin.com DO NOT DRAWI1 T30501-1 DLO

TEMPLATE NUMBER T3050 2/16/94