

**Notes:**

1. Do not scale drawing. Dimensions shown in inches(mm).
2. LHR door shown. Preparation is typical for both door hands.
3. Prepare mounting holes when installing the hardware.
4. Holes for optional SNB:  
3/8(9.50) Dia. Thru Transom.
5. Unless transom provides solid engagement for not less than (3) full screw threads, the SNB option is required.
6. Provide stiffeners, as required to prevent transom collapse due to installation with power tools, door use, or abuse.

**M67 (650F87) Auxiliary Bracket for ED5400 Series  
Surface Vertical Rod Exit Devices  
Application to Flush Transom**

**Corbin  
Russwin**®

www.corbinrusswin.com

SUPERSEDES T30881

DO NOT SCALE DRAWING

TEMPLATE NUMBER

**T30881-1**

DATE **9-99**