

**Notes:**

1. Do not scale drawing. Dimensions shown in inches(mm).
2. LHR Door shown. Preparation is typical or both door hands.
3. Prepare mounting holes when installing the hardware.
4. Provide adequate structural support to maintain transom rigidity and integrity after installation and during door operation.

**M67 (650F87) Auxiliary Bracket for ED5400 Series  
Surface Vertical Rod Exit Devices  
Application to Flush Wood Transom**

**Corbin  
Russwin**®

www.corbinrusswin.com

SUPERSEDES

DO NOT SCALE DRAWING

TEMPLATE NUMBER

**T30920**

DATE **9-99**