

V, R and L Escutcheon Trim


ML2000 Series Mortise Locks

For Museo® Series Designer Trim, refer to installation instructions FM601.



WARNING

This product can expose you to lead which is known to the state of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65warnings.ca.gov.



TOC


Table of Contents

1	Mortise Lock Handing Instructions	2
2	V Escutcheon Installation	3
3	R and L Escutcheon Installation.	5
4	Full Dummy R and L Escutcheon Installation.	7
5	Half Dummy R and L Escutcheon Installation	7
6	Installing Knobs Sold Before October 2017 ONLY:	8


1

Mortise Lock Handing Instructions


1. Move red locking screw to side of lockbody being locked.
2. Push in latch. Depress catch plate with screwdriver. (Figure 1)



3. Pull latch out of lock-body and turn latch over. (Figure 2)



4. Push in latch while holding screwdriver behind latch tail. (Figure 8)




NOTE:

Push in latch until catch plate is no longer depressed. (Figure 4)

Figure 4

5. Rotate lock front to match bevel of door, as shown. (Figure 10)



2

V Escutcheon Installation

1. Install strike using shorter 3/4" strike mounting screws. If strike box is needed, insert between strike and door frame. (Figure 6)




Figure 6

2. Insert mortise lock into door and hand tighten longer 1" mounting screws. (Figure 7)

NOTE:

Make sure lock is unlocked. If lock has a toggle, push bottom of toggle inward to unlock during installation.




Figure 7

3. Install spindles. (Figure 8)

NOTE:

Use correct spindle orientation. (Figure 9)




Figure 9




Figure 8

4. Mount escutcheon assemblies. (Figure 10)

NOTE:

Make sure turn-piece is oriented vertically when installing escutcheon.




Figure 10

2

V Escutcheon Installation, (cont.)

5. Install cylinder. Secure with cylinder set screw. (Figure 11)

NOTE:

- Pull key slightly out of cylinder to help thread into lockbody.
- Cylinder must be oriented correctly. (Figure 12)




Figure 11




Figure 12

6. Tighten lock mounting screws.

7. Install armored front. (Figure 13)




Figure 13

3

R and L Escutcheon Installation

1. Install strike using shorter 3/4" strike mounting screws. If strike box is needed, insert between strike and door frame. (Figure 14)




Figure 14

2. Insert mortise lock into door and hand tighten longer 1" mounting screws. (Figure 15)

NOTE:

Make sure lock is unlocked. If lock has a toggle, push bottom of toggle inward to unlock during installation.




Figure 15

3. Mount escutcheons. (Figure 16)

NOTE:

Make sure turn-piece is oriented vertically when installing escutcheon.




Figure 16

4. Install outside lever or knob by inserting adjustment bolt on opposite side of door. Tighten bolt finger-tight and loosen a few turns. (Figure 17)

NOTE:

Use correct spindle orientation. (Figure 18)




Figure 18




Figure 17

3

R and L Escutcheon Installation, (cont.)

5. Install inside lever or knob by inserting dowel screw. (Figure 19)

NOTE:

Make sure adjustment bolt hole is aligned with lever or knob hole. (Figure 23)




Figure 19




Figure 23

6. Install cylinder. Secure with cylinder set screw. (Figure 20)

NOTE:

- Pull key slightly out of cylinder to help thread into lockbody.
- Cylinder must be oriented correctly. (Figure 21)




Figure 20




Figure 21

7. Tighten lock mounting screws.

8. Install armored front. (Figure 22)





Figure 22

4

Full Dummy R and L Escutcheon Installation



1. Mount outside and inside escutcheon assemblies. (Figure 24)



5

Half Dummy R and L Escutcheon Installation

1. Install outside escutcheon assembly. (Figure 25)
2. Install mounting screws and washers. (Figure 26)





6**Installing Knobs Sold Before October 2017 ONLY:**

Before inserting knob lockbody into door, push spacer out of lock using a screwdriver.
(Figure 27)

NOTE:

Install spindles in square orientation.
(Figure 28)

**Figure 28****Figure 27**

Corbin Russwin
225 Episcopal Road
Berlin, CT 06037
Phone: 800-543-3658
Fax: 800-447-6714
corbinrusswin.com

ASSA ABLOY is the global
leader in door opening solutions,
dedicated to satisfying
end-user needs for security,
safety and convenience

Corbin Russwin is a brand associated with ASSA ABLOY Access and Egress Hardware Group, Inc., an ASSA ABLOY Group company. Copyright © 2018, ASSA ABLOY Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

For installation assistance contact Corbin Russwin
1-800-543-3658 • techsupport.corbinrusswin@assaabloy.com