



**NOTES:**

1. Do not scale.
2. Dimensions given in inches (mm).
3. For additional door preparations, see appropriate inside trim template.
4. Above door preparation identical for both LHRB and RHRB door.

**RESPONSIBILITY**

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

**MP9800 Series Multi-Point Lock  
Auxiliary Control  
Metal Door**



**ASSA ABLOY**

www.corbinruswin.com

SUPERSEDES	DO NOT SCALE DRAWING
TEMPLATE NUMBER	DATE
<b>T31240</b>	<b>08-16</b>