



**NOTES:**

1. TOLERANCE ON ALL DIMENSIONS IS  $\pm 1/64''$ .
2. WE RECOMMEND THAT ALL TAPPED HOLES BE DRILLED & TAPPED IN THE FIELD.
3. SEE STRIKE TEMPLATE FOR MOUNTING LOCATION OF STRIKE.  
FOR 881 MONITOR STRIKE SEE TEMPLATE MEDT47.
4. SEE MASTER SHEET No. MEDT23 FOR AREAS REQUIRING REINFORCEMENTS.
5. SURFACE OF DOOR WHERE EXIT DEVICE IS TO BE APPLIED MUST BE FLUSH.
6. FOR RACEWAY INFO, SEE TEMPLATES MEDT8.

**ASSA ABLOY**

Opening Solutions

Experience a safer  
and more open world  
©2010 ASSA ABLOY. A ASSA ABLOY COMPANY

TEMPLATE:  
NARROW DESIGN RIM TYPE  
EXIT DEVICE x EXIT TRIM, NO RIM CYLINDER  
FUNCTIONS

RELEASE DATE  
5/5/22

TEMPLATE NO.  
MEDT22