



- ⑥ FOR GLASS BEADED DOORS, IF GLASS BEAD CANNOT BE REMOVED, USE GLASS BEAD SHIM KIT (AVAILABLE ON ORDER).
- ⑤ SURFACE OF DOOR WHERE EXIT DEVICE IS TO BE APPLIED, MUST BE FLUSH.
- ④ SEE STRIKE TEMPLATE MEDT49 FOR 815 & MEDT50 FOR 90B STRIKES.
- ③ SEE MASTER SHEET MEDT23 FOR AREAS REQUIRING REINFORCEMENTS.
- ② ⑥ WE RECOMMEND THAT ALL TAPPED HOLES BE DRILLED & TAPPED IN FIELD.
- ① TOLERANCE ON ALL FRACTIONAL DIMENSIONS $\pm 1/64$ "

ASSA ABLOY
 Door Lock Division

TEMPLATE:
 MORTISE LOCK EXIT DEVICE

RELEASE DATE
 5/17/22
 TEMPLATE NO.
 MEDT42