



- NOTES:
1. DOOR PREPARATION SHOWN FOR INSIDE DOOR ONLY.
 2. IF OUTSIDE PULL AND/OR OUTSIDE CONTROL IS USED, SEE APPROPRIATE DOOR TEMPLATE FOR OUTSIDE DOOR PREP.
 3. "MIN BACKSET FOR SINGLE DOOR IS BASED ON 1/2" FRAME STOP. LARGER FRAME STOPS REQUIRE LARGER BACKSET.
 4. SURFACE OF DOOR WHERE EXIT DEVICE IS TO BE APPLIED, MUST BE FLUSH.
 5. WE RECOMMENDED THAT ALL TAPPED HOLES BE DRILLED AND TAPPED IN FIELD.
 6. TOLERANCE ALL FRACTIONAL DIMENSIONS ±1/64"
 7. BOTTOM AND TOP STRIKES MUST BE USED. SEE STRIKE TEMPLATE NO. MED7A.
 8. SEE TEMPLATE NO. MED17 FOR AUX CONTROL IF REQ'D.
 9. FOR DEVICES WITH NO BOTTOM ROD, HOLES FOR BOTTOM CASE ARE NOT REQUIRED.

TO BE USED FOR:
MD-PF8400
12-MD-PF8400
PED4800 MD
PED4800A MD

ASSA ABLOY Opening Solutions <small>Equipment made and most options</small>	RELEASE DATE
	05/02/22
TEMPLATE CONCEALED VERTICAL RODS FOR METAL DOORS (INSIDE FACE ONLY) EXIT DEVICE	TEMPLATE NO. MED13