
# **CUSTOM L019 INTERMEDIATE PIVOT, HANDED**

(1-3/4" THICK DOOR & 1-1/4" CLADDING)

## THIS TEMPLATE TO BE USED WITH SP-6461



3-1/2"


#### NOTES:

- 1. PIVOTS DRILLED FOR 1/4-20 x 3/4 FLAT HEAD METAL SCREW OR #14 x 2" FLAT HEAD WOOD SCREW.
- 2. REINFORCING BY OTHERS.
- 3. IT IS THE DOOR AND FRAME MANUFACTURERS RESPONSIBILITY TO CHECK THE HARDWARE SCHEDULE AND PREP THE DOORS AND FRAMES.
- 4. MAXIMUM DEGREE OF OPENING, 180°, TRIM PERMITTING.
- 5. RIGHT HAND SHOWN, LEFT HAND OPPOSITE.
- 6. DRAWING IS NOT TO SCALE.

CENTERLINE OF TOP PIVOTS MUST LINE UP

WITH CENTERLINE OF INTERMEDIATE PIVOTS &

BOTTOM PIVOT/CLOSER



**FRAME** 

R 3/16"

### **TOP VIEW**


## **INSTALLATION INSTRUCTIONS**

3-1/2

NOTE: DOOR SHOULD ALREADY BE HUNG WITH TOP PIVOT AND BOTTOM PIVOT (OR FLOOR CLOSER).



- 2. INSTALL L019 DOOR & FRAME PIVOT LEAVES.
- 3. ALIGN PIVOT POINT FROM TOP PIVOT TO BOTTOM ARM (SEE DRAWING).
- 4. REMOVE 019 END CAP.
- 5. TURN 019 RETAINER SCREW CLOCKWISE TO RAISE THE DOOR OR COUNTERCLOCKWISE TO LOWER DOOR UNTIL YOU REACH THE DESIRED HEIGHT.
- 6. TURN 019 RETAINER SCREW.
- 7. TIGHTEN 019 RETAINER SCREW UNTIL YOU FEEL RESISTENCE.
- 8. REPLACE 019 END CAP.



ITEM NO.	QTY.	PART NO.
1	1	L019 Door Leaf
2	1	019 Alignment Ball
3	1	019 Needle Bearing
4	1	L019 Jamb Leaf
5	1	019 Pivot Pin
6	1	019 Retainer Screw
7	1	019 End Cap

SP-6461.DWG



www.abhmfg.com
E-mail: abhinfo@abhmfg.com
Architectural Builders Hardware Mfg., Inc.
1222 Ardmore Ave., Itasca, IL 60143
630.875.9900; FAX 800.9FAXABH (932.9224)

© 2021 ABH Mfg., Inc. printed in USA

ISSUED 06-22-21

SP-6461-1