

ACTUAL SIZE DRAWING

THIS CAN BE USED AS A PAPER TEMPLATE

DIRECTIONS:

- 1. TRANSFER HOLE AND CUT OUT LOCATIONS TO THE FRAME OR WALL
- 2. CUT OUT OPENING ON FRAME OR WALL WHERE SHOWN BY DOTTED LINE
- 3. DRILL & TAP FOR TWO 6-32 MOUNTING SCREWS
- 4. CONNECT WIRING TO SWITCH
- 5. ATTACH PUSHPLATE USING INCLUDED HEX WRENCH



DynaLock Corporation 705 Emmett Street • Bristol, CT 06010 Tel: (860) 582-4761 • Fax: (860) 585-0338 Template Drawing

DRWN:	Date:	
	MJL	09/27/06
CHK'D:		Date:
	GG	09/28/06
CHK'D:		Date:
APPV'D:		Date:

6800 SERIES TEMPLATE

Page 1 Of 1 Scale: Size: Drawing #:

600335

REV: