

## **ACTUAL SIZE DRAWING**

## THIS CAN BE USED AS A PAPER TEMPLATE

## **DIRECTIONS:**

- 1. TRANSFER HOLE AND CUT OUT LOCATIONS TO THE FRAME OR WALL
- 2. CUT OUT OPENING ON FRAME OR WALL WHERE SHOWN BY DOTTED LINE
- 3. DRILL & TAP FOR TWO 6-32 MOUNTING SCREWS
- 4. CONNECT WIRING TO SWITCH
- 5. ATTACH PUSHPLATE USING INCLUDED HEX WRENCH



DynaLock Corporation 705 Emmett Street • Bristol, CT 06010 Tel: (860) 582-4761 • Fax: (860) 585-0338 Template Drawing

| П   | DRWN:  | Date: |                   |
|-----|--------|-------|-------------------|
|     |        | MJL   | 08/27/08          |
|     | CHK'D: | JAS   | Date:<br>08/29/08 |
|     | CHK'D: |       | Date:             |
| - 1 |        |       |                   |

Date:

APPV'D:

**6850 SERIES TEMPLATE** 

Page 1 Of 1

Scale: Size: Drawing #:

FULL A

600383

REV: