

Installation Guide - For Key in Lever Lock with #8 Style Rosette

Lock Assembly

Outside Trim

Flat spindle **MUST** be in horizontal position for installation

Inside Trim

Door Prep

1/8" Deep

2 3/8" or 2 3/4" Backset

2 1/4"

1"

2 1/8" Dia. Bore

1" Diameter Edge Bore

Re-pinning Cylinder (Optional)

Step 1. Small hole should face down.

Step 2. Rotate key counterclockwise 90° while pressing wire into hole.

For more information on rekeying cylinder, please scan the QR code for how-to video.

Step 3. Slide lever off stem.

1. Install Strike Plate

Fasten Strike Plate using Two #8 x 3/4" Wood Screws (provided).

Scan this QR code for installation video

2. Install Adjustable Latch

Fasten Adjustable Latch using two #8 x 3/4" Wood Screws (provided).

To remove Pin: Push Plastic Latch Pin through latch with screwdriver.

The Adjustable Latch is factory shipped with a 2 3/4" backset position. Remove pin and slide spindle forward for a 2 3/4" backset, then reinsert the pin in the hole at the back of the latch as shown.

2 3/4" Plastic Latch Pin

2 3/8" Plastic Latch Pin

3. Remove Inside Rosette

Step 1. Remove inside lever by loosening set screw w/ hex wrench (provided).

Step 2. Unthread rosette counterclockwise to remove from housing before installing on door.

Spanner wrench (provided).

4. Installing Inside Trim

Step 1. Secure inside rosette to door by threading it clockwise on to stem.

Plunger spindle **MUST** be in horizontal position for installation.

Step 2. Tighten lever set screw after placing lever on stem.