INSTRUCTIONS FOR INSTALLING SARGENT REPLACEMENT SPINDLE KIT 578

For assistance contact SARGENT at 800-727-5477 or www.sargentlock.com

SARGENT

ASSA ABLOY

ASSA ABLOY, the global leader in door opening solutions

TOOLS REQUIRED

- 1. 3/32" PUNCH
- 2. 1/4 " PUNCH
- 3. BALL PIEN HAMMER

STEP


1 PLACE OLD LEVER ASSEMBLY ON SOLID SURFACE. USE RAG OR PAD TO PREVENT MARRING FINISH.

STEP

② DRIVE OUT ROLL PIN USING 3/32" PUNCH . DISCARD PIN.

STEP

REMOVE OLD SPINDLE AND BUSHING.



STEP


INSTALL NEW SPINDLE ASSEMBLY INTO LEVER OPENING...ALIGN PIN HOLE IN LEVER SHANK.

STEP


PLACE NEW ROLL PIN IN HOLE OF LEVER.


STEP

DRIVE PIN FLUSH WITH LEVER USING 1/4" PUNCH.












STEP (8) APPLYING TEMPLATE

PLACE TEMPLATE EDGE AGAINST NYLON INSERT. ALIGN TEMPLATE PARALLEL WITH EDGE OF DOOR.



Copyright © 2006, 2008, Sargent Manufacturing Company, an ASSA ABLOY Group company. All rights reserved. Reproduction in whole or in part without the express written permission of Sargent Manufacturing Company is prohibited.





SARGENT[®] ASSA ABLOY

ASSA ABLOY, the global leader in door opening solutions