

# INSTALLATION INSTRUCTION FOR STRIKES

IF DOOR SILENCERS ARE  
USED ON THE DOOR FRAME,  
DECREASE THIS DIMENSION  
ACCORDINGLY.

Place shakeproof  
lockwasher between strike  
and frame or mullion

**STRIKE**

**Mounting Screws**

