

## PARALLEL ARM APPLICATION

#### INSTALLATION INSTRUCTIONS

1/2'

1-3/16"

ŧ

3-1/2"

1

5/16

DIM. B

**Ç OF HINGE POINT** 


-DIM. A


5-1/2

RFF

MAX DOOR OPENING	DIM. A	DIM. B
110°	4"	9 1/2"
180°	1 1/4"	6 3/4"

### **CLOSER MOUNTED ON STOP SIDE OF A DOOR**





FOR EXTERIOR DOORS AND WHERE STRONG DRAFT EXISTS INCREASE SPRING POWER AS NEEDED BY TURNING SPRING ADJUSTING NUT CLOCKWISE. IF NECESSARY, DECREASE SPRING POWER TO MEET REQUIREMENTS BY TURNING SPRING ADJUSTING NUT COUNTER CLOCKWISE.

NUMBER OF TURNS OF SPRING POWER ADJUSTING NUT* USE CHART AS GUIDE ONLY.					
DOOR WIDTH (INCHES)	APPROXIMATE DOOR WEIGHT (POUNDS)	1430 DOOR CLOSERS	し DOOR CLOSERS		
24	80	1-3 CCW			
30	110		FACTORY** SET		
32	115	FACTORY** SET			
36	130	521	4-7 CW		
40	150	1-3 CW			
42	155	1-3 CW	7-10 CW		
44	165	4-7 CW			
46	170	4-7 CW			
48	180	7-10 CW			
OVER 48		7-10 CW			

\* FOR EXTERIOR DOORS USE 1430 CLOSERS ONLY.


\*\* CLOSERS ARE FACTORY SET FOR INTERIOR DOORS.




ASSA ABLOY, the global leader in door opening solutions


Copyright © 2009, Sargent Manufacturing Company, an ASSA ABLOY Group company. All rights reserved. Reproduction in whole or in part without the express written permission of Sargent Manufacturing Company is prohibited. PAGE

3





#### SPRING ADJUSTMENT ADJUST SPRING POWER ACCORDING TO CHART.



FOR EXTERIOR DOORS AND WHERE STRONG DRAFT EXISTS INCREASE SPRING POWER AS NEEDED BY TURNING SPRING ADJUSTING NUT CLOCK-WISE. IF NECESSARY, DECREASE SPRING POWER TO MEET REQUIREMENTS BY TURNING SPRING ADJUSTING NUT COUNTER CLOCKWISE.

## 


NUMBER OF TURNS OF SPRING POWER ADJUSTING NUT* USE CHART AS GUIDE ONLY.					
DOOR WIDTH (INCHES)	APPROXIMATE DOOR WEIGHT (POUNDS)	1430 DOOR CLOSERS	し DOOR CLOSERS		
24	80				
30	110	1-3 CCW	1-3 CCW		
32	115		FACTORY**		
36	130	FACTORY**	SET		
40	150	SET	4-7 CW		
42	155	1-3	7-10 CW		
44	165	CW			
46	170	4-7			
48	180	CW			
OVER 48		7-10 CW			


\* FOR EXTERIOR DOORS USE 1430 CLOSERS ONLY. \*\* CLOSERS ARE FACTORY SET FOR INTERIOR DOORS.



ASSA ABLOY, the global leader in door opening solutions

Copyright © 2009, Sargent Manufacturing Company, an ASSA ABLOY Group company. All rights reserved. Reproduction in whole or in part without the express written permission of Sargent Manufacturing Company is prohibited. PAGE 5





# **USING MORTISE NUTS WITH SARGENT DOOR CLOSERS**

- 1. SEE INSTRUCTIONS OR DATA SHEET PACKED WITH DOOR CLOSER FOR DIMENSIONS LOCATING THE CLOSER BODY AND FOOT ON DOOR AND FRAME
- 2. MORTISE NUT SHOWN IS DESIGNED FOR AN UNREINFORCED METAL DOOR.
- 3. FOR TOP JAMB AND CORNER BRACKET APPLICATIONS: THE DOOR CLOSER FOOT WILL BE ATTACHED TO THE DOOR IN A MANNER SIMILAR TO THAT SHOWN FOR MOUNTING THE CLOSER BODY.
- 4. FOR DOORS 2 1/4" THICK: MORTISE NUT SHOWN FOR 1 3/4" THICK DOORS WILL BE FURNISHED ALONG WITH APPORPRIATE LENGTH THRU-BOLTS. DOOR CONSTRUCTION MUST PROVIDE A BRIDGE TYPE REINFORCEMENT TO PREVENT THE DOOR RAIL FROM COLLAPSING WHEN THRU-BOLTS ARE TIGHTENED.

