

ASSEMBLY OF DT-100 DOOR TOTE



1 With the axel installed through the axel tube, the wheels installed and secured with cotter pins, slide the short 3/4" bar into the upright tube and install with a detent pin as shown.

2 Next slide the long middle bar over the top and secure with another detent pin.



3 The long bar is installed next and secured through the second hole from the top.

See arrow

4 Place the top handle on and secure with the last detent pin.

The top handle can be adjusted for height by pulling the second pin from the top and using another set of holes.

