



714-772-5202 FAX 714-772-2302

web: www.majormfg.com

INSTRUCTIONS FOR USE WITH HIT-101 INSTALLATION TOOL FOR UNICAN 6000 SERIES LOCKS

Remove allen bolt and back plate. Place HIT-101 drill guide on door with aligning washers in the 2-1/8" crossbore. HIT-101 should be placed on door so the writing on the front plate is in the up right position. Replace back plate and tighten allen bolt until snug. Do not over tighten. HIT-101 is now ready to retrofit Unican 6000 series. All through bolt holes may be drilled in one operation through the door, or half way from both sides. This unit was designed to retrofit locks with 2-3/4" backsets. The use of this fixture for 2-3/8" backsets may be accomplished the following way. Mount the template to the door as usual (the tool will over hang the door edge 3/8"). Next with the use of a combination square, square the template to the door and tighten the allen bolt. The template is now in proper alignment for use.

DRILLING INSTRUCTIONS

1. Drill four 5/16" holes through door using the four bushings located at the four corners of the HIT-101. These holes can be drilled through from one side of the door or half way from both sides of the door.
2. Drill one 1/4" hole through door using the bushing located at the top of the HIT-101 below the two 5/16" holes. This hole can be drilled half way from both sides of the door. Enlarge this hole to 7/8" with the use of a hole saw after HIT-101 has been removed from door.
3. Install Unican 6000 series lock as per directions provided by the manufacturer.



Drill two-5/16" holes through door.

Drill one 1/4" hole through door, enlarge to 7/8" with the use of a hole saw after HIT-101 template has been removed from door.

Drill two-5/16" holes through door.