

145M Deadlatch Installation Instructions®

For Existing Door Preparation:

1. Insert latch into 1" diameter hole and fasten with 2 screws.
2. Push keyed assembly through 2-1/8" diameter hole from the inside and properly engage latch with the retractor.

IMPORTANT: PRONGS MUST ENGAGE CHASSIS AS SHOWN IN FIGURE 2.
3. Check from inside of door to make sure the latch is properly engaged before mounting the outside rose.
4. Position and align inside adapter with thru-bolts and secure with 2 short 10-32 F.H.M. screws.
5. Place and fasten inside assembly to adapter with 2 longer screws. Key must be inserted and turned to expose screw holes.
6. Check lock for proper operation before closing door.

