

REVEAL RANGE

1700BC Series

0"to 4-7/8"

(0) to (123)

J1700BC Series

4-7/8" to 6-7/8"


(123) to (174)

Notes:

Door swing may be limited by door, frame, wall or hardware conditions. Hollow-metal doors require channel or box-type reinforcement when thrubolt mount is specified.

Sex-bolts required for wood or plastic faced fire-door mounting.

Minimum thickness recommended for reinforcements in hollow-metal doors and frames: .1046" (2.66mm) unless otherwise noted.



- Do not scale drawing.
- Left hand door shown.
- Dimensions are: inches (millimeters)

PREPARATION FOR FASTENERS		
TYPE OF FASTENER	DOOR OR FRAME	PREPARATION
#14 Type "A" Sheet Metal Screw	Wood	7/32" (5.5mm)
1/4-20 Machine Screw	Hollow Metal	#7(.201 dia.) or 5.10mm. drill 1/4-20 tap
SNB (Sex Nut & Bolt) (Optional)	Hollow Metal	9/32" (7.00mm) thru 3/8" (9.50mm) door face Opposite to closer
	Aluminum or Wood	3/8" (9.50mm) thru
TBGN (Thru Bolt & Gronwest Nut) (Optional)	All	9/ 32" (7.00mm) thru 3/8" (9.50mm) diameter 3/8" (10mm) deep, door Face opposite to closer

1700BC or J1700BC Series Door Closers
Door and Frame Preparation Template
Top Jamb Application With Non Hold Open Arm



www.nortondoorcontrols.com

TEMPLATE NUMBER

DATE

7317-0051 | 01-09