



Installation Instructions:

1. Prepare door and frame per details shown.
2. To insure proper operation of door, the centerline of the top pivot pin must be straight and plumb with bottom spindle.
3. Install jamb portion with pin retracted.
4. Install door portion.
5. Place door on bottom pivot and raise door to vertical position.
6. Engage top pivot pin by turning adjusting screw clockwise when door portion is in alignment with the jamb portion.

Notes:

1. Do not scale drawing.
2. Dimensions are given in inches (mm).

**H340 Top Pivot
Center Hung
Non Handed**

RIXSON[®]
ASSA ABLOY

www.rixon.com

TEMPLATE NUMBER	REV	DATE
IS-H340	3	05-24