



### Installation Instructions:

1. Prepare door and frame per details shown.
2. To insure proper operation of door, the centerline of the top pivot pin must be straight and plumb with bottom spindle.
3. Install jamb portion with pin retracted.
4. Install door portion.
5. Place door on bottom pivot and raise door to vertical position.
6. Engage top pivot pin by turning adjusting screw clockwise when door portion is in alignment with the jamb portion.

### Notes:

1. Do not scale drawing.
2. Dimensions are given in inches (mm).

**320 Top Pivot  
Center Hung  
Non Handed**

**RIXSON<sup>®</sup>**  
**ASSA ABLOY**

www.rixon.com

TEMPLATE NUMBER

REV

DATE

**IS-320**

**3**

**05-24**

Approved 2024-05-24