



**Installation Instructions:**

1. Pivot point determined by bottom pivot or floor closer.
2. Prepare door and frame per details shown.
3. To insure proper operation of door, the centerline of the top pivot pin must be straight and plumb with bottom spindle.
4. Install walking beam with pin retracted.
5. Install 102 portion.
6. Place door on bottom pivot and raise door to vertical position.
7. Engage top pivot pin by turning adjusting screw clockwise when door portion is in alignment with the jamb portion.

**NOTES:**

1. Do not scale drawing.
2. Dimensions given in inches (mm).

**340 x 102 Top Pivot  
 Center Hung  
 Non Handed  
 Approved 2024-06-06**



TEMPLATE NUMBER	REV	DATE
IS-340x102	3	05/24