



Notes:

- Do not scale drawing.
- Left hand door shown for pull side.
- All dimensions are given in inches and millimeters.
- Recommended thickness for reinforcements in hollow-metal doors and frames should provide a combined material thickness of .164 (4.2) MIN.
- This template information based upon use of 5 (127) maximum width butt hinges or 3/4 (19) offset pivots.

**6011/6051 Series Operator Installation Template
Pull Side Mount
shown on 36" wide door**

For Reveal of 1/8" (3mm) max for 6011 or 1/8" (3mm) to 3" (76mm) for 6051

Norton®

ASSA ABLOY
www.nortondoorcontrols.com

TEMPLATE NUMBER	REV	DATE
80-7360-1036-020	1	05/20