



6011/6021/6031/6051/6061/6071 Template for installing conduit holes above frame (into wall)

Norton®

ASSA ABLOY

www.nortondoorcontrols.com

TEMPLATE NUMBER	REV	DATE
80-7360-1043-020	1	04/20